

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
AVB	Ames	A100	3/4	VUH	8	1-Nov-1991	1-Nov-2003		N	
AVB	Ames	A100	1	VUH	8	1-Nov-1991	1-Nov-2003		N	
AVB	Ames	A100	1 1/2	VUH	8	27-Sep-1991	27-Sep-2006		N	
AVB	Ames	A100	2	VUH	8	21-Aug-1991	21-Aug-2006		N	
AVB	Arrowhead Brass	58	1/2	H	6	18-Mar-1983	18-Mar-2004		N	
AVB	Champion Brass	162	1	H	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	162	1 1/4	H	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	162	1 1/2	H	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	162	2	H	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	162		H	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	262	3/4	VUH	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	262	1	VUH	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	262	1 1/4	VUH	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	262	1 1/2	VUH	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	262	2	VUH	7	13-Jan-1986	13-Jan-2004		N	
AVB	Champion Brass	362	3/4	VUH	7	13-Jan-1986	13-Jan-2004		Y	
AVB	Champion Brass	362	1	VUH	7	13-Jan-1986	13-Jan-2004		Y	
AVB	Champion Brass	466P	3/4	VUVD	7	13-Jan-1986	13-Jan-2004		Y	
AVB	Champion Brass	466P	1	VUVD	7	13-Jan-1986	13-Jan-2004		Y	
AVB	Rain Bird	APAS075	3/4	VUVD	6	22-Apr-1982	27-Apr-2006		N	
AVB	Rain Bird	DAS075	3/4	VUVD	6	22-Apr-1982	27-Apr-2006		N	
AVB	Strahman	HShorizontal	3/4	H	6	15-Sep-1981	15-Sep-2005		N	
AVB	Strahman	HSvertical	3/4	VD	6	5-Jun-1981	5-Jun-2005		N	
AVB	Watts	288AM3	1 1/4	VUH	8	12-Aug-1991	12-Aug-2006		N	
AVB	Watts	288AM3	1 1/2	VUH	8	27-Sep-1991	27-Sep-2006		N	
AVB	Watts	288AM3	2	VUH	8	21-Aug-1991	21-Aug-2006		N	
AVB	Watts	288AM3	2 1/2	VUH	8	10-Sep-1991	10-Sep-2006		N	
AVB	Watts	288AM3	3	VUH	8	16-Sep-1991	16-Sep-2006		N	
AVB	Watts	288AM5	3/4	VUH	8	1-Nov-1991	1-Nov-2003		N	
AVB	Watts	288AM5	1	VUH	8	1-Nov-1991	1-Nov-2003		N	
DC	Ames	2000B	1/2	H	8	6-Dec-1983	6-Dec-2004	(vv),xx	N	
DC	Ames	2000B	1/2	H	9	16-Jun-1997	16-Jun-2006	(vv),xx	N	
DC	Ames	2000B	1/2	VU	9	16-Jun-1997	16-Jun-2006	(vv),xx	N	
DC	Ames	2000B	3/4	H	8	5-Apr-1993	5-Apr-2005	(vv),xx	N	
DC	Ames	2000B	3/4	VU	8	27-Aug-1996	27-Aug-2005	(vv),xx	N	
DC	Ames	2000B	1	H	8	26-Feb-1991	26-Feb-2006	(vv),xx	N	
DC	Ames	2000B	1	H	9	18-May-1998	18-May-2004	(vv),xx	N	
DC	Ames	2000B	1	VU	9	18-May-1998	18-May-2004	(vv),xx	N	
DC	Ames	2000B	1 1/4	H	8	1-Oct-1996	1-Oct-2005	(vv),xx	N	
DC	Ames	2000B	1 1/4	VU	8	1-Oct-1996	1-Oct-2005	(vv),xx	N	
DC	Ames	2000B	1 1/2	H	8	24-May-1994	24-May-2006	(vv),xx	N	
DC	Ames	2000B	1 1/2	VU	8	11-Mar-1996	11-Mar-2005	(vv),xx	N	
DC	Ames	2000B	2	H	8	30-Jun-1992	30-Jun-2004	(vv),xx	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DC	Ames	2000B	2	VU	8	8-Mar-1996	8-Mar-2005	(vv),xx	N	
DC	Ames	2000BM3	3/4	H	9	27-Mar-2000	27-Mar-2006	(vv),xx	N	
DC	Ames	2000BM3	3/4	VU	9	27-Mar-2000	27-Mar-2006	(vv),xx	N	
DC	Ames	2000CIV	4	H	6	15-Jan-1982	15-Jan-2006	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
DC	Ames	2000CIV	4	VU	8	11-Mar-1996	11-Mar-2005	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
DC	Ames	2000CIV	6	H	6	18-May-1982	18-May-2006	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
DC	Ames	2000CIV	6	VU	8	5-Dec-1996	5-Dec-2005	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
DC	Ames	2000CIV	8	H	6	6-Jul-1981	6-Jul-2005	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
DC	Ames	2000CIV	8	VU	8	5-Dec-1996	5-Dec-2005	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
DC	Ames	2000CIV	10	H	6	16-Mar-1983	16-Mar-2004	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
DC	Ames	2000CIV	10	VU	8	5-Dec-1996	5-Dec-2005	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
DC	Ames	2000-DC	10	H	7	4-Aug-1987	2-Aug-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000-DCA	4	H	7	11-Jan-1988	11-Jan-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000-DCA	6	H	7	11-Jan-1988	11-Jan-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000-DCA	8	H	7	11-Jan-1988	11-Jan-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000-G-DC	10	H	7	4-Aug-1987	4-Aug-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000-G-DCA	4	H	7	11-Jan-1988	11-Jan-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000-G-DCA	6	H	7	11-Jan-1988	11-Jan-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000-G-DCA	8	H	7	11-Jan-1988	11-Jan-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SE	2 1/2	H	8	10-Sep-1996	10-Sep-2005	(mm),ee,ff,gg,hh,ll,mm,oo,pp,tt,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SE	6	H	8	22-Nov-1993	22-Nov-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SE	8	H	8	9-Sep-1992	9-Sep-2004	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SS	3/4	H	8	5-May-1995	5-May-2004	(ii)	Y	
DC	Ames	2000SS	1	H	8	5-May-1995	5-May-2004	(ii)	Y	
DC	Ames	2000SS	1 1/4	H	8	14-Jul-1995	14-Jul-2004	(ii)	Y	
DC	Ames	2000SS	1 1/2	H	8	13-Oct-1995	13-Oct-2004	(ii)	Y	
DC	Ames	2000SS	2	H	8	13-Oct-1995	13-Oct-2004	(ii)	Y	
DC	Ames	2000SS	2 1/2	H	8	11-Jul-1991	11-Jul-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SS	3	H	8	11-Jul-1991	11-Jul-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SS	4	H	8	11-Jul-1991	11-Jul-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SS	6	H	8	9-Sep-1992	9-Sep-2004	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SS	8	H	8	16-Sep-1996	16-Sep-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SS	10	H	8	16-Feb-2001	16-Feb-2004	(ll),mm,oo,pp,	N	
DC	Ames	2000SS-M	4	H	8	5-May-1995	5-May-2004	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	2000SS-M	6	H	8	5-May-1995	5-May-2004	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Ames	200B	1/2	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	200B	1/2	VD	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	200B	1/2	VU	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	200B	3/4	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	200B	3/4	VD	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	200B	3/4	VU	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	200B	1	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	200B	1	VD	9	21-Apr-2006		(vv),hhhh	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Ames	200B	1	VU	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	1 1/4	H	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	1 1/4	VD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	1 1/4	VU	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	1 1/2	H	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	1 1/2	VD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	1 1/2	VU	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	2	H	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	2	VD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B	2	VU	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B R10	1/2	H	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B R10	1/2	VD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B R10	1/2	VU	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B R10	3/4	H	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B R10	3/4	VD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B R10	3/4	VU	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B-A	1/2	VUVD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B-A	1	VUVD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B-A	1 1/4	VUVD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B-A	1 1/2	VUVD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	200B-A	2	VUVD	9	21-Apr-2006		(w),hhhh	N	
DC	Ames	Colt 200	2 1/2	H	9	20-Jul-2004		(ppp),qqq,yyy,zzz,dddd,eeee,dddd,gggg	N	
DC	Ames	Colt 200	2 1/2	VU	9	20-Jul-2004		(ppp),qqq,yyy,zzz,dddd,eeee,dddd,gggg	N	
DC	Ames	Colt 200	3	H	9	20-Jul-2004		(ppp),qqq,yyy,zzz,dddd,eeee,dddd,gggg	N	
DC	Ames	Colt 200	3	VU	9	20-Jul-2004		(ppp),qqq,yyy,zzz,dddd,eeee,dddd,gggg	N	
DC	Ames	Colt 200	4	H	9	20-Jul-2004		(ppp),qqq,yyy,zzz,dddd,eeee,dddd,gggg	N	
DC	Ames	Colt 200	4	VU	9	20-Jul-2004		(ppp),qqq,yyy,zzz,dddd,eeee,dddd,gggg	N	
DC	Ames	Colt 200	6	H	9	21-Apr-2006		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200	6	VU	9	21-Apr-2006		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200	8	H	9	11-Aug-2004		(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200	8	VU	9	10-Feb-2006		(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,gggg	N	
DC	Ames	Colt 200a	2 1/2	H	9	7-Oct-2002	7-Oct-2005	(ppp),fff,qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,gggg	N	
DC	Ames	Colt 200a	2 1/2	VU	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200a	3	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200a	3	VU	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200a	4	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200a	4	VU	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200a	6	H	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200a	6	VU	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200Na	2 1/2	VUVD	9	20-Mar-2003	20-Mar-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200Na	3	VUVD	9	20-Mar-2003	20-Mar-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200Na	4	VUVD	9	20-Mar-2003	20-Mar-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Colt 200Na	6	VUVD	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Ames	DC	4	H	6	14-Jun-1985	14-Jun-2006	oo,pp,ffff,gggg	Y	
DC	Ames	DC	6	H	6	14-Jun-1985	14-Jun-2006	oo,pp,ffff,gggg	Y	
DC	Ames	DC	8	H	7	4-Aug-1987	4-Aug-2005	oo,pp,ffff,gggg	Y	
DC	Ames	LF200B	1	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	1	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	1	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	1 1/4	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	1 1/4	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	1 1/4	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	1 1/2	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	1 1/2	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	1 1/2	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	2	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	2	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B	2	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B R10	1/2	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B R10	1/2	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B R10	1/2	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B R10	3/4	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B R10	3/4	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B R10	3/4	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B-A	1	VUVD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B-A	1 1/4	VUVD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B-A	1 1/2	VUVD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LF200B-A	2	VUVD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1 1/4	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1 1/4	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1 1/4	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1 1/2	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1 1/2	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	1 1/2	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	2	H	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	2	VD	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	LFU200B	2	VU	9	14-Jun-2006		(w), hhhh	N	
DC	Ames	Maxim 200	2 1/2	H	9	20-Jul-2004		(ppp),qqq,yyy,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200	2 1/2	VU	9	20-Jul-2004		(ppp),qqq,yyy,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200	3	H	9	20-Jul-2004		(ppp),qqq,yyy,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200	3	VU	9	20-Jul-2004		(ppp),qqq,yyy,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200	4	H	9	21-Apr-2006		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200	4	VU	9	21-Apr-2006		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Ames	Maxim 200	6	H	9	11-Aug-2004		(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200	6	VU	9	10-Feb-2006		(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200a	2 1/2	H	9	7-Oct-2002	7-Oct-2005	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200a	2 1/2	VU	9	7-Oct-2002	7-Oct-2005	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200a	3	H	9	7-Oct-2002	7-Oct-2005	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200a	3	VU	9	7-Oct-2002	7-Oct-2005	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200a	4	H	9	3-Jul-2003	3-Jul-2006	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200a	4	VU	9	3-Jul-2003	3-Jul-2006	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200Na	2 1/2	VUVD	9	20-Mar-2003	20-Mar-2006	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200Na	3	VUVD	9	20-Mar-2003	20-Mar-2006	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	Maxim 200Na	4	VUVD	9	3-Jul-2003	3-Jul-2006	(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Ames	U200B	1	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	1	VD	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	1	VU	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	1 1/4	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	1 1/4	VD	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	1 1/4	VU	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	1 1/2	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	1 1/2	VD	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	1 1/2	VU	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	2	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	2	VD	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200B	2	VU	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200BR10	1/2	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200BR10	1/2	VD	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200BR10	1/2	VU	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200BR10	3/4	H	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200BR10	3/4	VD	9	21-Apr-2006		(vv),hhhh	N	
DC	Ames	U200BR10	3/4	VU	9	21-Apr-2006		(vv),hhhh	N	
DC	Buckner	24100	3/4	H	8	1-Apr-1991	1-Apr-2006	(ii)	Y	
DC	Buckner	24101	1	H	8	1-Apr-1991	1-Apr-2006	(ii)	Y	
DC	Buckner	24102	1 1/4	H	8	1-Apr-1991	1-Apr-2006	(ii)	Y	
DC	Buckner	24103	1 1/2	H	8	1-Apr-1991	1-Apr-2006	(ii)	Y	
DC	Buckner	24104	2	H	8	1-Apr-1991	1-Apr-2006	(ii)	Y	
DC	Buckner	24100/25	3/4	H	8	1-Apr-1991	1-Apr-2006	(ii)	Y	
DC	Buckner	24101/25	1	H	8	1-Apr-1991	1-Apr-2006	(ii)	Y	
DC	Buckner	24102/25	1 1/4	H	8	31-Oct-1989	31-Oct-2004	(ii)	Y	
DC	Buckner	24103/25	1 1/2	H	8	31-Oct-1989	31-Oct-2004	(ii)	Y	
DC	Buckner	24104/25	2	H	8	31-Oct-1989	31-Oct-2004	(ii)	Y	
DC	Cla-Val	D2	3/4	H	5	19-Apr-1977	19-Apr-2004	(nn),dd	Y	
DC	Cla-Val	D2	1	H	5	19-Apr-1977	19-Apr-2004	(nn),dd	Y	
DC	Cla-Val	D2	1 1/4	H	5	6-Nov-1976	6-Nov-2003	(nn),dd	Y	
DC	Cla-Val	D2	1 1/2	H	5	6-Nov-1976	6-Nov-2003	(nn),dd	Y	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Cla-Val	D4	2	H	8	22-Jun-1989	22-Jun-2004	(nn),dd	Y	
DC	Cla-Val	D4	2 1/2	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
DC	Cla-Val	D4	3	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
DC	Cla-Val	D4	4	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
DC	Cla-Val	D4	6	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
DC	Cla-Val	D4	8	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
DC	Cla-Val	D4	10	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
DC	Conbraco	1/2DC	1/2	H	9	18-Sep-2000	18-Sep-2006	(dd)	N	
DC	Conbraco	1/2DC	1/2	VU	9	18-Sep-2000	18-Sep-2006	(dd)	N	
DC	Conbraco	10DC	10	H	9	16-Jan-2003	16-Jan-2006	(mm),ll	N	
DC	Conbraco	10DC	10	VU	9	16-Jan-2003	16-Jan-2006	(mm),ll	N	
DC	Conbraco	2 1/2DC	2 1/2	H	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	
DC	Conbraco	2 1/2DC	2 1/2	VU	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	
DC	Conbraco	2 1/2DC-7	2 1/2	H	9	23-Oct-2001	23-Oct-2004	(mm)[#1SOV], (qqq)[#2SOV]	N	
DC	Conbraco	2 1/2DC-7	2 1/2	VU	9	23-Oct-2001	23-Oct-2004	(mm)[#1SOV], (qqq)[#2SOV]	N	
DC	Conbraco	2 1/2DC8	2 1/2	H	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	2 1/2DC8	2 1/2	VU	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	2 1/2DCU	2 1/2	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	
DC	Conbraco	2 1/2DCU	2 1/2	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	
DC	Conbraco	3DC	3	H	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	
DC	Conbraco	3DC	3	VU	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	
DC	Conbraco	3DC7	3	H	9	23-Oct-2001	23-Oct-2004	(mm)[#1SOV], (qqq)[#2SOV]	N	
DC	Conbraco	3DC7	3	VU	9	23-Oct-2001	23-Oct-2004	(mm)[#1SOV], (qqq)[#2SOV]	N	
DC	Conbraco	3DC8	3	H	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	3DC8	3	VU	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	3DCU	3	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	
DC	Conbraco	3DCU	3	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	
DC	Conbraco	40-100-02	3	H	8	8-Apr-1991	8-Apr-2006	(tt),bb,ee,ll	N	
DC	Conbraco	40-100-03	3	H	8	8-Apr-1991	8-Apr-2006	(uu),cc,mm	N	
DC	Conbraco	40-100-05	3	H	8	8-Dec-1998	8-Dec-2004	(mmm)	N	
DC	Conbraco	40-103-02	1/2	H	8	1-May-1995	1-May-2004	(dd)	N	
DC	Conbraco	40-104-02	3/4	H	8	17-Mar-1989	17-Mar-2004	(dd)	N	
DC	Conbraco	40-104-A2	3/4	H	8	21-Jun-1993	21-Jun-2005	(dd)	N	
DC	Conbraco	40-104-A2T	3/4	H	8	25-Mar-1992	25-Mar-2004	(dd)	N	
DC	Conbraco	40-104-T2	3/4	H	8	27-Jun-1996	27-Jun-2005	(dd)	N	
DC	Conbraco	40-104-TC2	3/4	H	8	30-Nov-1998	30-Nov-2004	(dd)	N	
DC	Conbraco	40-105-02	1	H	8	17-Mar-1989	17-Mar-2004	(dd)	N	
DC	Conbraco	40-105-A2	1	H	8	21-Jun-1993	21-Jun-2005	(dd)	N	
DC	Conbraco	40-105-A2T	1	H	8	25-Mar-1992	25-Mar-2004	(dd)	N	
DC	Conbraco	40-105-T2	1	H	8	27-Jun-1996	27-Jun-2005	(dd)	N	
DC	Conbraco	40-105-TC2	1	H	8	30-Nov-1998	30-Nov-2004	(dd)	N	
DC	Conbraco	40-106-02	1 1/4	H	8	6-Apr-1992	6-Apr-2004	(dd)	N	
DC	Conbraco	40-106-A2	1 1/4	H	8	21-Jun-1993	21-Jun-2005	(dd)	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Conbraco	40-106-A2T	1 1/4	H	8	22-May-1993	22-May-2005	(dd)	N	
DC	Conbraco	40-106-T2	1 1/4	H	8	9-Oct-1996	9-Oct-2005	(dd)	N	
DC	Conbraco	40-107-02	1 1/2	H	8	17-Mar-1989	17-Mar-2004	(dd)	N	
DC	Conbraco	40-107-A2	1 1/2	H	8	22-May-1993	22-May-2005	(dd)	N	
DC	Conbraco	40-107-A2T	1 1/2	H	8	22-May-1993	22-May-2005	(dd)	N	
DC	Conbraco	40-107-T2	1 1/2	H	8	9-Oct-1996	9-Oct-2005	(dd)	N	
DC	Conbraco	40-108-02	2	H	8	17-Mar-1989	17-Mar-2004	(dd)	N	
DC	Conbraco	40-108-A2	2	H	8	22-May-1993	22-May-2005	(dd)	N	
DC	Conbraco	40-108-A2T	2	H	8	22-May-1993	22-May-2005	(dd)	N	
DC	Conbraco	40-108-T2	2	H	8	9-Oct-1996	9-Oct-2005	(dd)	N	
DC	Conbraco	40-109-02	2 1/2	H	8	8-Apr-1991	8-Apr-2006	(tt),bb,ee,ll	N	
DC	Conbraco	40-109-03	2 1/2	H	8	8-Apr-1991	8-Apr-2006	(uu),cc,mm	N	
DC	Conbraco	40-109-05	2 1/2	H	8	8-Dec-1998	8-Dec-2004	(mmm)	N	
DC	Conbraco	40-10A-02	4	H	8	8-Apr-1991	8-Apr-2006	(tt),bb,ee,ll	N	
DC	Conbraco	40-10A-03	4	H	8	8-Apr-1991	8-Apr-2006	(uu),cc,mm	N	
DC	Conbraco	40-10A-05	4	H	8	8-Dec-1998	8-Dec-2004	(mmm)	N	
DC	Conbraco	40-10A-06	4	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV], (nnn)[#2SOV]	N	
DC	Conbraco	40-10C-02	6	H	8	8-Apr-1991	8-Apr-2006	(tt),bb,ee,ll	N	
DC	Conbraco	40-10C-03	6	H	8	8-Apr-1991	8-Apr-2006	(uu),cc,mm	N	
DC	Conbraco	40-10C-05	6	H	8	8-Dec-1998	8-Dec-2004	(mmm)	N	
DC	Conbraco	40-10C-06	6	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV], (nnn)[#2SOV]	N	
DC	Conbraco	40-10E-02	8	H	8	22-Oct-1991	22-Oct-2006	(tt),bb,ee,ll	N	
DC	Conbraco	40-10E-03	8	H	8	22-Oct-1991	22-Oct-2006	(uu),cc,mm	N	
DC	Conbraco	40-10E-06	8	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV], (nnn)[#2SOV]	N	
DC	Conbraco	40-10G-02	10	H	8	13-Apr-1993	13-Apr-2005	(tt),bb,ee,ll	N	
DC	Conbraco	40-10G-03	10	H	8	13-Apr-1993	13-Apr-2005	(uu),cc,mm	N	
DC	Conbraco	40-10G-06	10	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV], (nnn)[#2SOV]	N	
DC	Conbraco	4DC	4	H	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	
DC	Conbraco	4DC	4	VU	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	
DC	Conbraco	4DC7	4	H	9	23-Oct-2001	23-Oct-2004	(mm)[#1SOV], (qqq)[#2SOV]	N	
DC	Conbraco	4DC7	4	VU	9	23-Oct-2001	23-Oct-2004	(mm)[#1SOV], (qqq)[#2SOV]	N	
DC	Conbraco	4DC8	4	H	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	4DC8	4	VU	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	4DCU	4	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	
DC	Conbraco	6DC	6	H	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	
DC	Conbraco	6DC	6	VU	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	
DC	Conbraco	6DC7	6	H	9	23-Oct-2001	23-Oct-2004	(mm)[#1SOV], (qqq)[#2SOV]	N	
DC	Conbraco	6DC7	6	VU	9	23-Oct-2001	23-Oct-2004	(mm)[#1SOV], (qqq)[#2SOV]	N	
DC	Conbraco	6DC8	6	H	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	6DC8	6	VU	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	6DCU	6	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	
DC	Conbraco	8DC	8	H	9	16-Jan-2003	16-Jan-2006	(mm),ll	N	
DC	Conbraco	8DC	8	VU	9	16-Jan-2003	16-Jan-2006	(mm),ll	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Conbraco	8DC8	8	H	9	29-Sep-2004		(ppp),qqq	N	
DC	Conbraco	8DC8	8	VU	9	29-Sep-2004		(ppp),qqq	N	
DC	Febco	805	3/4	H	4	29-Apr-1974	29-Apr-2004		Y	
DC	Febco	805	1	H	4	29-Apr-1974	29-Apr-2004		Y	
DC	Febco	805	1 1/2	H	4	29-Apr-1974	29-Apr-2004		Y	
DC	Febco	805	2	H	4	29-Apr-1974	29-Apr-2004		Y	
DC	Febco	805	3	H	4	26-Oct-1973	26-Oct-2006		Y	
DC	Febco	805	4	H	4	26-Oct-1973	26-Oct-2006		Y	
DC	Febco	805Y	3/4	H	6	13-May-1982	13-May-2006	(ii),fff,jjj,ooo	N	
DC	Febco	805Y	1	H	6	13-May-1982	13-May-2006	(ii),fff,jjj,ooo	N	
DC	Febco	805Y	1 1/2	H	6	5-Jan-1983	5-Jan-2004	(ii),fff,jjj,ooo	N	
DC	Febco	805Y	2	H	6	5-Jan-1983	5-Jan-2004	(ii),fff,ooo	N	
DC	Febco	805Y	2 1/2	H	6	7-Mar-1983	7-Mar-2004		Y	
DC	Febco	805Y	3	H	6	4-Aug-1982	4-Aug-2006		Y	
DC	Febco	805Y	4	H	6	4-Aug-1982	4-Aug-2006		Y	
DC	Febco	805Y	6	H	5	26-Aug-1977	26-Aug-2004		Y	
DC	Febco	805Y	8	H	5	26-Aug-1977	26-Aug-2004		Y	
DC	Febco	805Y	10	H	5	31-May-1978	31-May-2005		Y	
DC	Febco	805YB	3/4	H	8	4-May-1994	4-May-2006	(ii),fff,jjj,ooo	N	
DC	Febco	805YB	3/4	VU	8	16-Apr-1996	16-Apr-2005	(ii),fff,jjj,ooo	N	
DC	Febco	805YD	2 1/2	H	7	31-May-1987	31-May-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	805YD	3	H	7	31-May-1987	31-May-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	805YD	4	H	7	31-May-1987	31-May-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	805YD	6	H	7	31-May-1987	31-May-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	805YD	8	H	7	31-May-1987	31-May-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	805YD	10	H	7	31-May-1987	31-May-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	805YR	3/4	H	8	22-Jan-1993	22-Jan-2005	(ii),fff,jjj,ooo	N	
DC	Febco	805YR	1	H	8	22-Jan-1993	22-Jan-2005	(ii),fff,jjj,ooo	N	
DC	Febco	830H	4	H	9	24-Apr-2004		(int)	N	
DC	Febco	830H	4	VU	9	2-Jun-2004		(int)	N	
DC	Febco	850	1/2	H	9	21-Nov-1997	21-Nov-2003	(fff),ooo	N	
DC	Febco	850	1/2	VD	9	13-Apr-2000	13-Apr-2006	(fff),ooo	N	
DC	Febco	850	1/2	VU	9	17-Dec-1999	17-Dec-2005	(fff),ooo	N	
DC	Febco	850	3/4	H	9	21-Nov-1997	21-Nov-2003	(fff),jjj,ooo	N	
DC	Febco	850	3/4	VD	9	10-Apr-2000	10-Apr-2006	(fff),jjj,ooo	N	
DC	Febco	850	3/4	VU	9	17-Dec-1999	17-Dec-2005	(fff),jjj,ooo	N	
DC	Febco	850	1	H	9	21-Nov-1997	21-Nov-2003	(fff),jjj,ooo	N	
DC	Febco	850	1	VD	9	14-Jan-2000	14-Jan-2006	(fff),jjj,ooo	N	
DC	Febco	850	1	VU	9	7-Sep-2000	7-Sep-2006	(fff),jjj,ooo	N	
DC	Febco	850	1 1/4	H	9	21-Nov-1997	21-Nov-2003	(fff),jjj,ooo	N	
DC	Febco	850	1 1/4	VD	9	13-Apr-2000	13-Apr-2006	(fff),jjj,ooo	N	
DC	Febco	850	1 1/4	VU	9	17-Jul-1999	17-Jul-2005	(fff),jjj,ooo	N	
DC	Febco	850	1 1/2	H	9	19-Feb-1998	19-Feb-2004	(fff),jjj,ooo	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Febco	850	1 1/2	VD	9	13-Apr-2000	13-Apr-2006	(fff),jii,ooo	N	
DC	Febco	850	1 1/2	VU	9	17-Jul-1999	17-Jul-2005	(fff),jjj,ooo	N	
DC	Febco	850	2	H	9	19-Feb-1998	19-Feb-2004	(fff),ooo	N	
DC	Febco	850	2	VD	9	10-Apr-2000	10-Apr-2006	(fff),ooo	N	
DC	Febco	850	2	VU	9	17-Jul-1999	17-Jul-2005	(fff),ooo	N	
DC	Febco	850	2 1/2	H	8	14-Mar-1997	14-Mar-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	850	2 1/2	VU	8	19-Mar-1997	19-Mar-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	850	3	H	8	14-Mar-1997	14-Mar-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	850	3	VU	8	19-Mar-1997	19-Mar-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	850	4	H	8	4-May-1994	4-May-2006	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
DC	Febco	850	4	VU	8	7-Feb-1995	7-Feb-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
DC	Febco	850	6	H	8	4-May-1994	4-May-2006	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
DC	Febco	850	6	VU	8	31-May-1995	31-May-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
DC	Febco	850	8	H	8	4-Oct-1995	4-Oct-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
DC	Febco	850	8	VU	8	14-Oct-1996	14-Oct-2005	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
DC	Febco	850F	3/4	H	9	28-Sep-2001	28-Sep-2004	(fff),jjj	N	
DC	Febco	850F	3/4	VD	9	28-Sep-2001	28-Sep-2004	(fff),jjj	N	
DC	Febco	850F	3/4	VU	9	28-Sep-2001	28-Sep-2004	(fff),jjj	N	
DC	Febco	850U	1/2	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
DC	Febco	850U	1/2	VD	9	16-Oct-2000	16-Oct-2006	(kkk)	N	
DC	Febco	850U	1/2	VU	9	17-Dec-1999	17-Dec-2005	(kkk)	N	
DC	Febco	850U	3/4	H	9	8-Mar-1999	8-Mar-2005	(kkk)	N	
DC	Febco	850U	3/4	VD	9	16-Oct-2000	16-Oct-2006	(kkk)	N	
DC	Febco	850U	3/4	VU	9	17-Dec-1999	17-Dec-2005	(kkk)	N	
DC	Febco	850U	1	H	9	4-Aug-1999	4-Aug-2005	(kkk)	N	
DC	Febco	850U	1	VD	9	14-Jan-2000	14-Jan-2006	(kkk)	N	
DC	Febco	850U	1	VU	9	16-Oct-2000	16-Oct-2006	(kkk)	N	
DC	Febco	850U	1 1/4	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
DC	Febco	850U	1 1/4	VD	9	16-Oct-2000	16-Oct-2006	(kkk)	N	
DC	Febco	850U	1 1/4	VU	9	4-Aug-1999	4-Aug-2005	(kkk)	N	
DC	Febco	850U	1 1/2	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
DC	Febco	850U	1 1/2	VD	9	16-Oct-2000	16-Oct-2006	(kkk)	N	
DC	Febco	850U	1 1/2	VU	9	4-Aug-1999	4-Aug-2005	(kkk)	N	
DC	Febco	850U	2	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
DC	Febco	850U	2	VD	9	16-Oct-2000	16-Oct-2006	(kkk)	N	
DC	Febco	850U	2	VU	9	4-Aug-1999	4-Aug-2005	(kkk)	N	
DC	Febco	857	2 1/2	H	8	1-Aug-2006		(oo),gg,hh,ll,mm,pp,tt,uu,yy,fff	N	
DC	Febco	857	2 1/2	VU	8	1-Aug-2006		(oo),gg,hh,ll,mm,pp,tt,uu,yy,fff	N	
DC	Febco	857	3	H	8	1-Aug-2006		(oo),gg,hh,ll,mm,pp,tt,uu,yy,fff	N	
DC	Febco	857	3	VU	8	1-Aug-2006		(oo),gg,hh,ll,mm,pp,tt,uu,yy,fff	N	
DC	Febco	870	2 1/2	VUVD	8	10-Mar-1995	10-Mar-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	870	3	VUVD	8	10-Mar-1995	10-Mar-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	870	4	VUVD	8	4-May-1994	4-May-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DC	Febco	870	6	VUVD	8	4-May-1994	4-May-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	870	8	VUVD	8	24-May-1994	24-May-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	870	10	VUVD	8	4-Oct-1996	4-Oct-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
DC	Febco	870V	2 1/2	VUVD	8	8-Mar-1996	8-Mar-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	2 1/2	VUVU	8	8-Mar-1996	8-Mar-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	3	VUVD	8	8-Mar-1996	8-Mar-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	3	VUVU	8	8-Mar-1996	8-Mar-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	4	VUVD	8	8-Mar-1996	8-Mar-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	4	VUVU	8	8-Mar-1996	8-Mar-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	6	VUVD	8	8-Mar-1996	8-Mar-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	6	VUVU	8	8-Mar-1996	8-Mar-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	8	VUVD	8	6-Jan-1997	6-Jan-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	8	VUVU	8	6-Jan-1997	6-Jan-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	10	VUVD	8	11-Jul-1997	11-Jul-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Febco	870V	10	VUVU	8	11-Jul-1997	11-Jul-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
DC	Flomatic	DCV	3/4	H	8	4-May-1994	4-May-2006	(ii)	N	
DC	Flomatic	DCV	1	H	8	4-May-1994	4-May-2006	(ii)	N	
DC	Flomatic	DCV	1 1/2	H	8	10-May-1995	10-May-2004	(ii)	N	
DC	Flomatic	DCV	2	H	8	10-May-1995	10-May-2004	(ii)	N	
DC	Flomatic	DCV	2 1/2	H	8	14-Feb-1997	14-Feb-2006	(gg),hh,jj,kk,ll,mm,yy,zz,ccc,ddd	N	
DC	Flomatic	DCV	3	H	8	14-Feb-1997	14-Feb-2006	(gg),hh,jj,kk,ll,mm,yy,zz,ccc,ddd	N	
DC	Flomatic	DCV	4	H	9	1-Jul-1999	1-Jul-2005	(gg),hh,jj,kk,ll,mm,yy,zz,ccc,ddd	N	
DC	Flomatic	DCV	6	H	9	31-Jan-2002	31-Jan-2005	(gg),hh,jj,kk,ll,mm,yy,zz,ccc,ddd	N	
DC	Flomatic	DCV	8	H	9	9-Nov-2004		(mm), hh, jj, kk, ll, gg, yy, zz, ccc, ddd	N	
DC	Flomatic	DCVE	3/4	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
DC	Flomatic	DCVE	1	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
DC	Flomatic	DCVE	1 1/2	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
DC	Flomatic	DCVE	2	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
DC	Hersey/Grinnell	2	3	H	5	27-Dec-1978	27-Dec-2005	(tt),bb,qq,iii,III	Y	
DC	Hersey/Grinnell	2	4	H	5	27-Dec-1978	27-Dec-2005	(tt),bb,qq,iii,III	Y	
DC	Hersey/Grinnell	2	6	H	5	22-Dec-1978	22-Dec-2005	(tt),bb,qq,iii,III	Y	
DC	Hersey/Grinnell	2	8	H	6	6-Jul-1981	6-Jul-2005	(tt),bb,qq,iii,III	Y	
DC	Hersey/Grinnell	2	10	H	6	19-Feb-1982	19-Feb-2006	(tt),bb,qq,iii,III	Y	
DC	Neptune									
DC	RainBird									
DC	Watts	007	2 1/2	H	8	30-Sep-1990	30-Sep-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
DC	Watts	007	2 1/2	VU	8	27-Aug-1996	27-Aug-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
DC	Watts	007	3	H	8	30-Sep-1990	30-Sep-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	007	3	VU	8	27-Aug-1996	27-Aug-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	007M1PCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(vv),xx	N	
DC	Watts	007M1PCQT	1	H	8	10-Dec-1993	10-Dec-2005	(vv),xx	N	
DC	Watts	007M1PCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
DC	Watts	007M1PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DC	Watts	007M1QT	3/4	H	8	26-Feb-1991	26-Feb-2006	(w),xx	Y	
DC	Watts	007M1QT	1	H	8	26-Feb-1991	26-Feb-2006	(w),xx	N	
DC	Watts	007M1QT	1	H	9	18-May-1998	18-May-2004	(w),xx	N	
DC	Watts	007M1QT	1	VU	9	18-May-1998	18-May-2004	(w),xx	N	
DC	Watts	007M1QT	1 1/2	H	8	30-Jun-1992	30-Jun-2004	(w),xx	Y	
DC	Watts	007M1QT	2	H	8	30-Jun-1992	30-Jun-2004	(w),xx	N	
DC	Watts	007M1QT	2	VU	8	8-Mar-1996	8-Mar-2005	(w),xx	N	
DC	Watts	007M2PCQT	1 1/4	H	8	9-Dec-1996	9-Dec-2005	(w),xx	N	
DC	Watts	007M2PCQT	1 1/4	VU	8	9-Dec-1996	9-Dec-2005	(w),xx	N	
DC	Watts	007M2PCQT	1 1/2	H	8	12-Sep-1994	12-Sep-2006	(w),xx	N	
DC	Watts	007M2QT	3/4	H	8	5-Apr-1993	5-Apr-2005	(w),xx	N	
DC	Watts	007M2QT	3/4	VU	8	27-Aug-1996	27-Aug-2005	(w),xx	N	
DC	Watts	007M2QT	1 1/4	H	8	1-Oct-1996	1-Oct-2005	(w),xx	N	
DC	Watts	007M2QT	1 1/4	VU	8	1-Oct-1996	1-Oct-2005	(w),xx	N	
DC	Watts	007M2QT	1 1/2	H	8	24-May-1994	24-May-2006	(w),xx	N	
DC	Watts	007M2QT	1 1/2	VU	8	11-Mar-1996	11-Mar-2005	(w),xx	N	
DC	Watts	007M3QT	3/4	H	9	18-Oct-1999	18-Oct-2005	(w),xx	N	
DC	Watts	007M3QT	3/4	VU	9	18-Oct-1999	18-Oct-2005	(w),xx	N	
DC	Watts	007PCQT	1/2	H	8	17-Feb-1995	17-Feb-2004	(w),xx	N	
DC	Watts	007PCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
DC	Watts	007PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
DC	Watts	007QT	1/2	H	8	6-Dec-1993	6-Dec-2005		N	
DC	Watts	007QT	1/2	H	9	16-Jun-1997	16-Jun-2006	(w),xx	N	
DC	Watts	007QT	3/4	H	7	11-Jan-1988	11-Jan-2006		Y	
DC	Watts	007QT	1	H	7	11-Jan-1988	11-Jan-2006		Y	
DC	Watts	007QT`	1/2	VU	8	19-Apr-1996	19-Apr-2005		N	
DC	Watts	007QT`	1/2	VU	9	16-Jun-1997	16-Jun-2006	(w),xx	N	
DC	Watts	007QT`	1 1/2	H	7	21-Jul-1988	21-Jul-2006		Y	
DC	Watts	007QT`	2	H	7	21-Jul-1988	21-Jul-2006		Y	
DC	Watts	007SSM1PCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(w),xx	Y	
DC	Watts	007SSM1PCQT	1	H	8	10-Dec-1993	10-Dec-2005	(w),xx	Y	
DC	Watts	007SSM1QT	3/4	H	8	26-Feb-1991	26-Feb-2006	(w),xx	Y	
DC	Watts	007SSM1QT	1	H	8	26-Feb-1991	26-Feb-2006	(w),xx	Y	
DC	Watts	007SSPCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
DC	Watts	007SSPCQT	2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
DC	Watts	007SSQT	3/4	H	7	11-Jan-1988	11-Jan-2006		Y	
DC	Watts	007SSQT	1	H	7	11-Jan-1988	11-Jan-2006		Y	
DC	Watts	007SSQT	1 1/2	H	7	21-Jul-1988	21-Jul-2006		Y	
DC	Watts	007SSQT	2	H	7	21-Jul-1988	21-Jul-2006		Y	
DC	Watts	700	2 1/2	H	5	10-Jan-1981	10-Jan-2005		Y	
DC	Watts	700	3	H	5	10-Jan-1981	10-Jan-2005		Y	
DC	Watts	709	2 1/2	H	7	12-Jun-1986	12-Jun-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
DC	Watts	709	3	H	7	12-Jun-1986	12-Jun-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DC	Watts	709	4	H	6	15-Jan-1982	15-Jan-2006	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	709	4	VU	8	11-Mar-1996	11-Mar-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	709	6	H	6	18-May-1982	18-May-2006	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	709	6	VU	8	5-Dec-1996	5-Dec-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	709	8	H	6	6-Jul-1981	6-Jul-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	709	8	VU	8	5-Dec-1996	5-Dec-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	709	10	H	6	16-Mar-1983	16-Mar-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	709	10	VU	8	5-Dec-1996	5-Dec-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
DC	Watts	709BB	2 1/2	H	6	20-Jul-1982	20-Jul-2006	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
DC	Watts	709BB	3	H	6	20-Jul-1982	20-Jul-2006	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
DC	Watts	709QT	3/4	H	6	4-Aug-1982	4-Aug-2006	(vv),xx	Y	
DC	Watts	709QT	1	H	6	4-Aug-1982	4-Aug-2006	(vv),xx	Y	
DC	Watts	709QT	1 1/2	H	6	27-Apr-1982	27-Apr-2006	(vv),xx	Y	
DC	Watts	709QT	2	H	6	27-Apr-1982	27-Apr-2006	(vv),xx	Y	
DC	Watts	709QT-FDA	2 1/2	H	8	30-Sep-1990	30-Sep-2005	(ww),ffff,gggg	N	
DC	Watts	709QT-FDA	3	H	8	30-Sep-1990	30-Sep-2005	(ww),ffff,gggg	N	
DC	Watts	709QT-FDA	4	H	8	30-Sep-1990	30-Sep-2005	(ww),ffff,gggg	N	
DC	Watts	709QT-FDA	6	H	8	30-Sep-1990	30-Sep-2005	(ww),ffff,gggg	N	
DC	Watts	709QT-FDA	8	H	8	30-Sep-1990	30-Sep-2005	(ww),ffff,gggg	N	
DC	Watts	709QT-FDA	10	H	8	30-Sep-1990	30-Sep-2005	(ww),ffff,gggg	N	
DC	Watts	719AQT	1/2	VUVD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719AQT	1	VUVD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719AQT	1 1/4	VUVD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719AQT	1 1/2	VUVD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719AQT	2	VUVD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1/2	H	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1/2	VD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1/2	VU	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	3/4	H	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	3/4	VD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	3/4	VU	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1	H	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1	VD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1	VU	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1 1/4	H	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1 1/4	VD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1 1/4	VU	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1 1/2	H	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1 1/2	VD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	1 1/2	VU	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	2	H	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	2	VD	9	4-Oct-2005		(vv),hhhh	N	
DC	Watts	719QT	2	VU	9	4-Oct-2005		(vv),hhhh	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Watts	719QTR10	1/2	H	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	719QTR10	1/2	VD	9	4-Oct-2005		(vw),hhhh	N	
DC	Watts	719QTR10	1/2	VU	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	719QTR10	3/4	H	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	719QTR10	3/4	VD	9	4-Oct-2005		(vw),hhhh	N	
DC	Watts	719QTR10	3/4	VU	9	4-Oct-2005		(vw),hhhh	N	
DC	Watts	757	2 1/2	H	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	2 1/2	VU	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	3	H	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	3	VU	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	4	H	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	4	VU	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	6	H	9	21-Apr-2006		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	6	VU	9	21-Apr-2006		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	8	H	9	16-Sep-2004		(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757	8	VU	9	10-Feb-2006		(yyy), ppp, qqq,zzz, aaaa, bbbb, dddd, eeee, ffff, gggg	N	
DC	Watts	757a	2 1/2	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757a	2 1/2	VU	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757a	3	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757a	3	VU	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757a	4	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757a	4	VU	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757a	6	H	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757a	6	VU	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757Na	2 1/2	VUVD	9	20-Mar-2003	20-Mar-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757Na	3	VUVD	9	20-Mar-2003	20-Mar-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757Na	4	VUVD	9	20-Mar-2003	20-Mar-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	757Na	6	VUVD	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767	2 1/2	H	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767	2 1/2	VU	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767	3	H	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767	3	VU	9	29-Sep-2004		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767	4	H	9	21-Apr-2006		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767	4	VU	9	21-Apr-2006		(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767	6	H	9	16-Sep-2004		(yyy),ppp,qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767	6	VU	9	10-Feb-2006		(yyy), ppp, qqq,zzz, aaaa, bbbb, dddd, eeee, ffff, gggg	N	
DC	Watts	767a	2 1/2	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767a	2 1/2	VU	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767a	3	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767a	3	VU	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767a	4	H	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767a	4	VU	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767Na	2 1/2	VUVD	9	20-Mar-2003	20-Mar-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DC	Watts	767Na	3	VUVD	9	20-Mar-2003	20-Mar-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	767Na	4	VUVD	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
DC	Watts	770	4	H	8	20-May-1992	20-May-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy	Y	
DC	Watts	770	8	H	8	13-Jan-1993	13-Jan-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy	Y	
DC	Watts	770QTFDA	4	H	8	12-Jan-1993	13-Jan-2005	(ww)	Y	
DC	Watts	770QTFDA	8	H	8	12-Jan-1993	13-Jan-2005	(ww)	Y	
DC	Watts	772	4	H	8	1-Jul-1992	1-Jul-2004	(oo),yy	Y	
DC	Watts	772	10	H	8	13-Jan-1993	13-Jan-2005	(oo),yy	Y	
DC	Watts	774	3/4	H	8	5-May-1995	5-May-2004	(ii)	Y	
DC	Watts	774	1	H	8	5-May-1995	5-May-2004	(ii)	Y	
DC	Watts	774	1 1/4	H	8	14-Jul-1995	14-Jul-2004	(ii)	Y	
DC	Watts	774	1 1/2	H	8	13-Oct-1995	13-Oct-2004	(ii)	Y	
DC	Watts	774	2 1/2	H	8	11-Jul-1991	11-Jul-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Watts	774	3	H	8	11-Jul-1991	11-Jul-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Watts	774	4	H	8	11-Jul-1991	11-Jul-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Watts	774	6	H	8	9-Sep-1992	9-Sep-2004	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Watts	774	8	H	8	16-Sep-1996	16-Sep-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Watts	774	10	H	8	16-Feb-2001	16-Feb-2004	(ll),mm,ffff,gggg	N	
DC	Watts	774X	2 1/2	H	8	10-Sep-1996	10-Sep-2005	(mm),ee,ff,gg,hh,ll,oo,pp,tt,uu,ccc,ddd,ffff,gggg	N	
DC	Watts	774X	6	H	8	22-Nov-1993	22-Nov-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Watts	774X	8	H	8	9-Sep-1992	9-Sep-2004	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
DC	Watts	775QT	1/2	H	9	1-Feb-2000	1-Feb-2006	(int)	N	
DC	Watts	775QT	1/2	VU	9	1-Feb-2000	1-Feb-2006	(int)	N	
DC	Watts	775QT	3/4	H	9	1-Feb-2000	1-Feb-2006	(int)	N	
DC	Watts	775QT	3/4	VU	9	1-Feb-2000	1-Feb-2006	(int)	N	
DC	Watts	775QT	1	H	9	12-Aug-1999	12-Aug-2005	(int)	N	
DC	Watts	775QT	1	VU	9	12-Aug-1999	12-Aug-2005	(int)	N	
DC	Watts	775QT	1 1/4	H	9	7-Sep-2000	7-Sep-2006	(int)	N	
DC	Watts	775QT	1 1/4	VU	9	7-Sep-2000	7-Sep-2006	(int)	N	
DC	Watts	775QT	1 1/2	H	9	7-Sep-2000	7-Sep-2006	(int)	N	
DC	Watts	775QT	1 1/2	VU	9	7-Sep-2000	7-Sep-2006	(int)	N	
DC	Watts	775QT	2	H	9	28-Mar-2002	28-Mar-2005	(int)	N	
DC	Watts	775QT	2	VU	9	28-Mar-2002	28-Mar-2005	(int)	N	
DC	Watts	LF719AQT	1	VUVD	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719AQT	1 1/4	VUVD	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719AQT	1 1/2	VUVD	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719AQT	2	VUVD	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719QT	1	H	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719QT	1	VD	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719QT	1	VU	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719QT	1 1/4	H	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719QT	1 1/4	VD	9	22-Aug-2005		(vv), hhhh	N	
DC	Watts	LF719QT	1 1/4	VU	9	22-Aug-2005		(vv), hhhh	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Watts	LF719QT	1 1/2	H	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QT	1 1/2	VD	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QT	1 1/2	VU	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QT	2	H	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QT	2	VD	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QT	2	VU	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QTR10	1/2	H	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QTR10	1/2	VD	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QTR10	1/2	VU	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QTR10	3/4	H	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QTR10	3/4	VD	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LF719QTR10	3/4	VU	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1	H	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1	VD	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1	VU	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1 1/4	H	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1 1/4	VD	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1 1/4	VU	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1 1/2	H	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1 1/2	VD	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	1 1/2	VU	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	2	H	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	2	VD	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	LFU719QT	2	VU	9	22-Aug-2005		(w), hhhh	N	
DC	Watts	SS007M1QT	1	H	9	18-May-1998	18-May-2004	(hhh)	N	
DC	Watts	SS007M1QT	1	VU	9	18-May-1998	18-May-2004	(hhh)	N	
DC	Watts	SS007M3QT	1/2	H	9	11-Sep-2000	11-Sep-2006	(hhh)	N	
DC	Watts	SS007M3QT	1/2	VU	9	11-Sep-2000	11-Sep-2006	(hhh)	N	
DC	Watts	SS007M3QT	3/4	H	9	7-Sep-2000	7-Sep-2006	(hhh)	N	
DC	Watts	SS007M3QT	3/4	VU	9	7-Sep-2000	7-Sep-2006	(hhh)	N	
DC	Watts	U007M1APCQT	3/4	VDVD	8	10-Dec-1994	10-Dec-2003	(w),xx	N	
DC	Watts	U007M1APCQT	3/4	VDVU	8	10-Dec-1994	10-Dec-2003	(w),xx	N	
DC	Watts	U007M1APCQT	3/4	VUVD	8	10-Dec-1994	10-Dec-2003	(w),xx	N	
DC	Watts	U007M1APCQT	3/4	VUVU	8	10-Dec-1994	10-Dec-2003	(w),xx	N	
DC	Watts	U007M1APCQT	2	VDVD	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
DC	Watts	U007M1APCQT	2	VDVU	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
DC	Watts	U007M1APCQT	2	VUVD	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
DC	Watts	U007M1APCQT	2	VUVU	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
DC	Watts	U007M1AQT	3/4	VDVD	8	24-Feb-1994	24-Feb-2006	(w),xx	N	
DC	Watts	U007M1AQT	3/4	VDVU	8	24-Feb-1994	24-Feb-2006	(w),xx	N	
DC	Watts	U007M1AQT	3/4	VUVD	8	24-Feb-1994	24-Feb-2006	(w),xx	N	
DC	Watts	U007M1AQT	3/4	VUVU	8	24-Feb-1994	24-Feb-2006	(w),xx	N	
DC	Watts	U007M1AQT	2	VDVD	8	24-Feb-1994	24-Feb-2006	(w),xx	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Watts	U007M1AQT	2	VDVU	8	24-Feb-1994	24-Feb-2006	(w),xx	N	
DC	Watts	U007M1AQT	2	VUVD	8	24-Feb-1994	24-Feb-2006	(w),xx	N	
DC	Watts	U007M1AQT	2	VUVU	8	24-Feb-1994	24-Feb-2006	(w),xx	N	
DC	Watts	U007M1PCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(w),xx	N	
DC	Watts	U007M1PCQT	1	H	8	10-Dec-1993	10-Dec-2005	(w),xx	N	
DC	Watts	U007M1PCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
DC	Watts	U007M1PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
DC	Watts	U007M1QT	3/4	H	8	30-Aug-1993	30-Aug-2005	(w),xx	N	
DC	Watts	U007M1QT	1	H	8	30-Aug-1993	30-Aug-2005	(w),xx	N	
DC	Watts	U007M1QT	1 1/2	H	8	20-Oct-1993	20-Oct-2005	(w),xx	Y	
DC	Watts	U007M1QT	2	H	8	20-Oct-1993	20-Oct-2005	(w),xx	N	
DC	Watts	U007M2AQT	1 1/2	VDVD	8	6-Sep-1994	6-Sep-2006	(w),xx	N	
DC	Watts	U007M2AQT	1 1/2	VDVU	8	6-Sep-1994	6-Sep-2006	(w),xx	N	
DC	Watts	U007M2AQT	1 1/2	VUVD	8	6-Sep-1994	6-Sep-2006	(w),xx	N	
DC	Watts	U007M2AQT	1 1/2	VUVU	8	6-Sep-1994	6-Sep-2006	(w),xx	N	
DC	Watts	U007M2QT	1 1/4	H	8	1-Oct-1996	1-Oct-2005	(w),xx	N	
DC	Watts	U007M2QT	1 1/2	H	8	6-Sep-1994	6-Sep-2006	(w),xx	N	
DC	Watts	U007PCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(w),xx	Y	
DC	Watts	U007PCQT	1	H	8	10-Dec-1993	10-Dec-2005	(w),xx	Y	
DC	Watts	U007PCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
DC	Watts	U007PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
DC	Watts	U007QT	1/2	H	9	8-Mar-1999	8-Mar-2005	(w),xx	N	
DC	Watts	U007QT	1/2	VU	9	8-Mar-1999	8-Mar-2005	(w),xx	N	
DC	Watts	U007QT	3/4	H	7	11-Jan-1988	11-Jan-2006	(w),xx	Y	
DC	Watts	U007QT	1	H	7	11-Jan-1988	11-Jan-2006	(w),xx	Y	
DC	Watts	U007QT	1 1/2	H	7	21-Jul-1988	21-Jul-2006	(w),xx	Y	
DC	Watts	U007QT	2	H	7	21-Jul-1988	21-Jul-2006	(w),xx	Y	
DC	Watts	U007SSPCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(w),xx	Y	
DC	Watts	U007SSPCQT	1	H	8	10-Dec-1993	10-Dec-2005	(w),xx	Y	
DC	Watts	U007SSPCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
DC	Watts	U007SSPCQT	2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
DC	Watts	U007SSQT	3/4	H	7	11-Jan-1988	11-Jan-2006	(w),xx	Y	
DC	Watts	U007SSQT	1	H	7	11-Jan-1988	11-Jan-2006	(w),xx	Y	
DC	Watts	U007SSQT	1 1/2	H	7	21-Jul-1988	21-Jul-2006	(w),xx	Y	
DC	Watts	U007SSQT	2	H	7	21-Jul-1988	21-Jul-2006	(w),xx	Y	
DC	Watts	U719QT	1	H	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	1	VD	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	1	VU	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	1 1/4	H	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	1 1/4	VD	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	1 1/4	VU	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	1 1/2	H	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	1 1/2	VD	9	4-Oct-2005		(w),hhhh	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Watts	U719QT	1 1/2	VU	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	2	H	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	2	VD	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QT	2	VU	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QTR10	1/2	H	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QTR10	1/2	VD	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QTR10	1/2	VU	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QTR10	3/4	H	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QTR10	3/4	VD	9	4-Oct-2005		(w),hhhh	N	
DC	Watts	U719QTR10	3/4	VU	9	4-Oct-2005		(w),hhhh	N	
DC	Wilkins	350	3/4	H	9	6-Jul-2005		(ii),ooo	N	
DC	Wilkins	350	3/4	VU	9	6-Jul-2005		(ii),ooo	N	
DC	Wilkins	350	1	H	9	21-Apr-2006		(ii),ooo	N	
DC	Wilkins	350	1	VU	9	21-Apr-2006		(ii),ooo	N	
DC	Wilkins	350	2 1/2	H	9	5-Sep-2001	5-Sep-2004	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
DC	Wilkins	350	2 1/2	VU	9	3-Apr-2002	3-Apr-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
DC	Wilkins	350	3	H	9	5-Sep-2001	5-Sep-2004	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
DC	Wilkins	350	3	VU	9	3-Apr-2002	3-Apr-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
DC	Wilkins	350	4	H	9	15-Sep-1999	15-Sep-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
DC	Wilkins	350	4	VU	9	7-Sep-2000	7-Sep-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
DC	Wilkins	350	6	H	9	18-Oct-1999	18-Oct-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
DC	Wilkins	350	6	VU	9	17-Dec-1999	17-Dec-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
DC	Wilkins	350	8	H	9	8-Mar-2002	8-Mar-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
DC	Wilkins	350	8	VU	9	16-Jan-2003	16-Jan-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
DC	Wilkins	350	10	H	9	28-Aug-2002	28-Aug-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
DC	Wilkins	350	10	VU	9	14-Mar-2003	14-Mar-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
DC	Wilkins	350A	2 1/2	H	9	22-Jun-2005		(ppp),sss,ttt,qqq,yyy,zzz,dddd	N	
DC	Wilkins	350A	2 1/2	VU	9	22-Jun-2005		(ppp),sss,ttt,qqq,yyy,zzz,dddd	N	
DC	Wilkins	350A	3	H	9	22-Jun-2005		(ppp),sss,ttt,qqq,yyy,zzz,dddd	N	
DC	Wilkins	350A	3	VU	9	22-Jun-2005		(ppp),sss,ttt,qqq,yyy,zzz,dddd	N	
DC	Wilkins	350A	4	H	9	16-Mar-2004		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	350A	4	VU	9	16-Mar-2004		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	350A	6	H	9	25-Nov-2003		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	350A	6	VU	9	25-Nov-2003		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	350A	8	H	9	12-Feb-2004		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	350A	8	VU	9	12-Feb-2004		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	350A	10	H	9	6-Apr-2006		(ppp),qqq,sss,ttt	N	
DC	Wilkins	350A	10	VU	9	6-Apr-2006		(ppp),qqq,sss,ttt	N	
DC	Wilkins	350XL	3/4	H	9	30-Aug-2006		(iiii)	N	
DC	Wilkins	350XL	3/4	VU	9	30-Aug-2006		(iiii)	N	
DC	Wilkins	350XL	1	H	9	27-Oct-2006		(iii)	N	
DC	Wilkins	350XL	1	VU	9	27-Oct-2006		(iii)	N	
DC	Wilkins	450	2 1/2	VUVD	9	24-Jan-2002	24-Jan-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DC	Wilkins	450	3	VUVD	9	24-Jan-2002	24-Jan-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
DC	Wilkins	450	4	VUVD	9	12-Apr-2000	12-Apr-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	450	6	VUVD	9	24-May-2000	24-May-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	450	8	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
DC	Wilkins	450	10	VUVD	9	11-Sep-2003	11-Sep-2006	(ppp),qqq,sss,ttt,www,zzz,dddd,eeee	N	
DC	Wilkins	550	3/4	H	5	11-Oct-1976	11-Oct-2006		Y	
DC	Wilkins	550	1	H	5	11-Oct-1976	11-Oct-2006		Y	
DC	Wilkins	550	1 1/4	H	5	11-Oct-1976	11-Oct-2006	(ii)	Y	
DC	Wilkins	550	1 1/2	H	5	11-Oct-1976	11-Oct-2006	(ii)	Y	
DC	Wilkins	550	1 1/2	H	5	11-Oct-1976	11-Oct-2006	(ii)	Y	
DC	Wilkins	550	2	H	5	11-Oct-1976	11-Oct-2006	(ii)	Y	
DC	Wilkins	550	2 1/2	H	7	25-Sep-1986	25-Sep-2004	(gg),ee,tt,yy	Y	
DC	Wilkins	550	3	H	5	20-Aug-1979	20-Aug-2006	(gg),ee,tt,yy	Y	
DC	Wilkins	550	4	H	5	20-Jun-1980	20-Jun-2004	(gg),ee,tt,yy	Y	
DC	Wilkins	550	6	H	6	6-Jul-1981	6-Jul-2005	(gg),ee,tt,yy	Y	
DC	Wilkins	550A	3/4	H	7	17-Apr-1987	17-Apr-2005	(ii)	Y	
DC	Wilkins	550A	1	H	7	17-Apr-1987	17-Apr-2005	(ii)	Y	
DC	Wilkins	550M	8	H	8	15-Mar-1989	15-Mar-2004	(gg),ee,tt,yy	Y	
DC	Wilkins	550M	10	H	6	11-Apr-1983	11-Apr-2004	(gg),ee,tt,yy	Y	
DC	Wilkins	950	3/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
DC	Wilkins	950	1	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
DC	Wilkins	950	1 1/4	H	8	5-Apr-1991	5-Apr-2006	(ii)	N	
DC	Wilkins	950	1 1/2	H	8	5-Apr-1991	5-Apr-2006	(ii)	N	
DC	Wilkins	950	2	H	8	5-Apr-1991	5-Apr-2006	(ii)	N	
DC	Wilkins	950	2 1/2	H	8	26-Nov-1991	26-Nov-2003	(gg),ee,ff,hh,tt,uu,yy,zz	N	
DC	Wilkins	950	3	H	8	8-Nov-1991	8-Nov-2003	(gg),ee,ff,hh,tt,uu,yy,zz	N	
DC	Wilkins	950	4	H	8	8-Nov-1991	8-Nov-2003	(gg),ee,ff,hh,tt,uu,yy,zz,ppp	N	
DC	Wilkins	950	4	VU	8	29-Aug-1995	29-Aug-2004	(gg),ee,ff,hh,tt,uu,yy,zz,ppp	N	
DC	Wilkins	950	6	H	8	18-Mar-1992	18-Mar-2004	(gg),ee,ff,hh,tt,uu,yy,zz,ppp	N	
DC	Wilkins	950	6	VU	8	29-Aug-1995	29-Aug-2004	(gg),ee,ff,hh,tt,uu,yy,zz,ppp	N	
DC	Wilkins	950	8	H	8	18-Mar-1989	18-Mar-2004	(gg),ee,ff,hh,tt,uu,yy,zz	N	
DC	Wilkins	950	8	VU	8	29-Aug-1995	29-Aug-2004	(gg),ee,ff,hh,tt,uu,yy,zz	N	
DC	Wilkins	950	10	H	8	12-Apr-1994	12-Apr-2006	(gg),ee,ff,hh,tt,uu,yy,zz	N	
DC	Wilkins	950A	3/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
DC	Wilkins	950A	1	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
DC	Wilkins	950A	1 1/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
DC	Wilkins	950A	1 1/2	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
DC	Wilkins	950A	2	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
DC	Wilkins	950XL	3/4	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo	N	
DC	Wilkins	950XL	3/4	VU	8	12-Dec-1996	12-Dec-2005	(ii),ooo	N	
DC	Wilkins	950XL	1	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo	N	
DC	Wilkins	950XL	1 1/4	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo,ggg	N	
DC	Wilkins	950XL	1 1/2	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DC	Wilkins	950XL	2	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo	N	
DC	Wilkins	950XLD	3/4	H	9	15-Sep-1999	15-Sep-2005	(ii),ooo	N	
DC	Wilkins	950XLD	3/4	VU	9	5-Jan-2000	5-Jan-2006	(ii),ooo	N	
DC	Wilkins	950XLT	3/4	H	9	9-May-1997	9-May-2006	(ii),ooo	N	
DC	Wilkins	950XLT	1	H	9	9-May-1997	9-May-2006	(ii),ooo	N	
DC	Wilkins	950XLT	1 1/4	H	9	19-Jun-1998	19-Jun-2004	(ii),ooo	N	
DC	Wilkins	950XLT	1 1/2	H	9	9-Apr-1998	9-Apr-2004	(ii),ooo	N	
DC	Wilkins	950XLT	2	H	9	9-Apr-1998	9-Apr-2004	(ii),ooo	N	
DC	Wilkins	950XLTU	3/4	H	9	14-Aug-2006		(ggg)	N	
DC	Wilkins	950XLTU	1	H	9	14-Aug-2006		(ggg)	N	
DC	Wilkins	950XLU	3/4	H	8	15-Feb-1994	15-Feb-2006	(ggg)	N	
DC	Wilkins	950XLU	1	H	8	15-Feb-1994	15-Feb-2006	(ggg)	N	
DC	Wilkins	950XLU	1 1/2	H	8	15-Feb-1994	15-Feb-2006	(ggg)	N	
DC	Wilkins	950XLU	2	H	8	15-Feb-1994	15-Feb-2006	(ggg)	N	
DCDA	Ames	3000B	2	H	9	16-Jun-1997	16-Jun-2006	(bbb)	N	Ames 2000B 1/2" (H), Watts 007QT 1/2" (H)
DCDA	Ames	3000B	2	VU	9	16-Jun-1997	16-Jun-2006	(bbb)	N	Ames 2000B 1/2" (VU), Watts 007QT 1/2" (VU)
DCDA	Ames	3000CIV	4	H	6	27-Jul-1987	27-Jul-2005	(pp),hh,uu,eee	N	Ames 2000B 1/2"(H),Watts 007QT 1/2"(H)
DCDA	Ames	3000CIV	4	VU	8	27-Aug-1996	27-Aug-2005	(pp),hh,uu,eee	N	Ames 2000B 1/2"(VU),Watts 007QT 1/2"(VU)
DCDA	Ames	3000CIV	6	H	6	27-Jul-1987	27-Jul-2005	(pp),hh,uu,eee	N	Ames 2000B 1/2"(H),Watts 007QT 1/2"(H)
DCDA	Ames	3000CIV	6	VU	8	5-Dec-1996	5-Dec-2005	(pp),hh,mm,uu,eee	N	Ames 2000B 1/2" (VU), Watts 007QT 1/2" (VU)
DCDA	Ames	3000CIV	8	H	6	19-Apr-1987	19-Apr-2005	(pp),hh,mm,uu,eee	N	Ames 2000B 1/2"(H),Watts 007QT 1/2"(H)
DCDA	Ames	3000CIV	8	VU	8	5-Dec-1996	5-Dec-2005	(pp),hh,mm,uu,eee	N	Ames 2000B 1/2" (VU), Watts 007QT 1/2" (VU)
DCDA	Ames	3000CIV	10	H	6	27-Jul-1987	27-Jul-2005	(pp),hh,mm,uu,eee	N	Ames 2000B 1/2"(H),Watts 007QT 1/2"(H)
DCDA	Ames	3000CIV	10	VU	8	5-Dec-1996	5-Dec-2005	(pp),hh,mm,uu,eee	N	Ames 2000B 1/2" (VU), Watts 007QT 1/2" (VU)
DCDA	Ames	3000DCDA	4	H	7	11-Jan-1988	11-Jan-2006	(uu),ee,ff,gg,hh,mm,oo,pp,ccc,ddd,fff,gggg	Y	Watts 007QT 3/4" (H)
DCDA	Ames	3000DCDA	6	H	7	11-Jan-1988	11-Jan-2006	(uu),ee,ff,gg,hh,mm,oo,pp,ccc,ddd,fff,gggg	Y	Watts 709QT 3/4" (H)
DCDA	Ames	3000DCDA	8	H	7	11-Jan-1988	11-Jan-2006	(uu),ee,ff,gg,hh,mm,oo,pp,ccc,ddd,fff,gggg	Y	Watts 007QT 3/4" (H)
DCDA	Ames	3000DCDC	10	H	7	4-Aug-1987	4-Aug-2005	(uu),ee,ff,gg,hh,oo,pp,ccc,ddd,fff,gggg	N	Watts007M2QT 3/4" (H),Watts 709QT 3/4" (H), Ames 2000B 3/4" (H)
DCDA	Ames	3000GDCDA	4	H	7	11-Jan-1988	11-Jan-2006	(uu),ee,ff,gg,hh,mm,oo,pp,ccc,ddd,fff,gggg	Y	Watts 007QT 3/4" (H)
DCDA	Ames	3000GDCDA	6	H	7	11-Jan-1988	11-Jan-2006	(uu),ee,ff,gg,hh,mm,oo,pp,ccc,ddd,fff,gggg	Y	Watts 709QT 3/4" (H)
DCDA	Ames	3000GDCDA	8	H	7	11-Jan-1988	11-Jan-2006	(uu),ee,ff,gg,hh,mm,oo,pp,ccc,ddd,fff,gggg	Y	Watts 007QT 3/4" (H)
DCDA	Ames	3000GDCDC	10	H	7	4-Aug-1987	4-Aug-2005	(uu),ee,ff,gg,hh,oo,pp,ccc,ddd,fff,gggg	Y	Watts 709QT 3/4" (H)
DCDA	Ames	3000SE	2 1/2	H	8	10-Sep-1996	10-Sep-2005	(mm),ee,ff,gg,hh,ll,oo,pp,tt,uu,ccc,ddd,fff,gggg	N	Watts007M2QT 3/4" (H), Ames 2000B 3/4" (H)
DCDA	Ames	3000SE	6	H	8	24-May-1995	24-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts007M2QT 3/4" (H), Ames 2000B 3/4" (H)
DCDA	Ames	3000SE	8	H	8	9-Sep-1992	9-Sep-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts 007M1QT 3/4" (H)
DCDA	Ames	3000SEA	8	H	8	5-May-1995	5-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	Y	Ames 2000SS 3/4" (H)
DCDA	Ames	3000SEWM1	6	H	8	22-Nov-1993	22-Nov-2005	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts 007M1QT 3/4" (H)
DCDA	Ames	3000SS	2 1/2	H	8	24-May-1995	24-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts007M2QT 3/4" (H), Ames 2000B 3/4" (H)
DCDA	Ames	3000SS	3	H	8	24-May-1995	24-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts007M2QT 3/4" (H), Ames 2000B 3/4" (H)
DCDA	Ames	3000SS	4	H	8	24-May-1995	24-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts007M2QT 3/4" (H), Ames 2000B 3/4" (H)
DCDA	Ames	3000SS	6	H	8	9-Sep-1992	9-Sep-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts 007M1QT 3/4" (H)
DCDA	Ames	3000SS	8	H	8	16-Sep-1996	16-Sep-2005	(uu),ee,ff,gg,hh,ll,mm,tt,ccc,ddd,fff,gggg	N	Watts007M2QT 3/4" (H), Ames 2000B 3/4" (H)
DCDA	Ames	3000SS	10	H	8	16-Feb-2001	16-Feb-2004	(ll),mm,oo,pp,fff,gggg	N	Ames 2000B 3/4" (H)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DCDA	Ames	3000SSA	6	H	8	5-May-1995	5-May-2004	(uu,ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	Y	Ames 2000SS 3/4" (H)
DCDA	Ames	3000SSM	4	H	8	5-May-1995	5-May-2004	(uu,ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	Y	Ames 2000SS 1" (H)
DCDA	Ames	3000SSM	6	H	8	5-May-1995	5-May-2004	(uu,ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	N	Watts 007M2QT 1 1/2" (H)
DCDA	Ames	3000SSWM1	2 1/2	H	8	11-Jul-1991	11-Jul-2006	(uu,ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	N	Watts 007M1QT 3/4" (H)
DCDA	Ames	3000SSWM1	3	H	8	11-Jul-1991	11-Jul-2006	(uu,ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	N	Watts 007M1QT 3/4" (H)
DCDA	Ames	3000SSWM1	4	H	8	11-Jul-1991	11-Jul-2006	(uu,ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	N	Watts 007M1QT 3/4" (H)
DCDA	Ames	Colt 300aBF	2 1/2	H	9	6-Nov-2003		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300aBF	2 1/2	VU	9	6-Nov-2003		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300aBF	3	H	9	6-Nov-2003		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300aBF	3	VU	9	6-Nov-2003		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300aBF	4	H	9	6-Nov-2003		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300aBF	4	VU	9	6-Nov-2003		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300aBF	6	H	9	29-Sep-2004		(yyy)	N	Ames 3/4" Model 2000Bm3 (H) DC
DCDA	Ames	Colt 300aBF	6	VU	9	18-Jan-2005		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300aGV	2 1/2	H	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300aGV	2 1/2	VU	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300aGV	3	H	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300aGV	3	VU	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300aGV	4	H	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300aGV	4	VU	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300aGV	6	H	9	3-Nov-2004		(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300aGV	6	VU	9	18-Jan-2005		(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300BF	2 1/2	H	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300BF	2 1/2	VU	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300BF	3	H	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300BF	3	VU	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300BF	4	H	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300BF	4	VU	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300GV	2 1/2	H	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300GV	2 1/2	VU	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300GV	3	H	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300GV	3	VU	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Colt 300GV	4	H	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Colt 300GV	4	VU	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	DCDC	4	H	6	14-Jun-1985	14-Jun-2006	ee,ff,gg,hh,oo,pp,ccc,ddd,ffff,gggg	Y	Watts 709QT 3/4" (H)
DCDA	Ames	DCDC	6	H	6	14-Jun-1985	14-Jun-2006	ee,ff,gg,hh,oo,pp,ccc,ddd,ffff,gggg	Y	Watts 709QT 3/4" (H)
DCDA	Ames	DCDC	8	H	7	4-Aug-1987	4-Aug-2005	ee,ff,gg,hh,oo,pp,ccc,ddd,ffff,gggg	Y	Watts 709QT 3/4" (H)
DCDA	Ames	Maxim 300aBF	2 1/2	H	9	6-Nov-2003		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300aBF	2 1/2	VU	9	6-Nov-2003		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Maxim 300aBF	3	H	9	6-Oct-2003	6-Oct-2006	(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300aBF	3	VU	9	6-Oct-2003	6-Oct-2006	(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Maxim 300aBF	4	H	9	3-Nov-2004		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300aBF	4	VU	9	18-Jan-2005		(yyy)	N	Ames 2000BM3 3/4" (VU)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DCDA	Ames	Maxim 300aGV	2 1/2	H	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300aGV	2 1/2	VU	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Maxim 300aGV	3	H	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300aGV	3	VU	9	6-Oct-2003	6-Oct-2006	(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Maxim 300aGV	4	H	9	3-Nov-2004		(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300aGV	4	VU	9	18-Jan-2005		(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Maxim 300BF	2 1/2	H	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300BF	2 1/2	VU	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Maxim 300BF	3	H	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300BF	3	VU	9	4-Oct-2005		(yyy)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Maxim 300GV	2 1/2	H	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300GV	2 1/2	VU	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Ames	Maxim 300GV	3	H	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (H)
DCDA	Ames	Maxim 300GV	3	VU	9	4-Oct-2005		(zzz)	N	Ames 2000BM3 3/4" (VU)
DCDA	Conbraco	10DCDA	10	H	9	16-Jan-2003	16-Jan-2006	(mm),ll	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	10DCDA	10	VU	9	16-Jan-2003	16-Jan-2006	(mm),ll	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	2 1/2DCDA	2 1/2	H	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	2 1/2DCDA	2 1/2	VU	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	2 1/2DCDA6	2 1/2	H	9	10-Apr-2001	10-Apr-2004	(mm)[#1SOV],(nnn)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	2 1/2DCDA6	2 1/2	VU	9	10-Apr-2001	10-Apr-2004	(mm)[#1SOV],(nnn)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	2 1/2DCDA7	2 1/2	H	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	2 1/2DCDA7	2 1/2	VU	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	2 1/2DCDA8	2 1/2	H	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	2 1/2DCDA8	2 1/2	VU	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	2 1/2DCDAU	2 1/2	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	3DCDA	3	H	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	3DCDA	3	VU	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	3DCDA6	3	H	9	10-Apr-2001	10-Apr-2004	(mm)[#1SOV],(nnn)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	3DCDA6	3	VU	9	10-Apr-2001	10-Apr-2004	(mm)[#1SOV],(nnn)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	3DCDA7	3	H	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	3DCDA7	3	VU	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	3DCDA8	3	H	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	3DCDA8	3	VU	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	3DCDAU	3	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	40600C3	3	H	8	20-Aug-1996	20-Aug-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	40600E3	3	H	8	20-Aug-1996	20-Aug-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060AC3	4	H	8	13-Apr-1993	13-Apr-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060AC6	4	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV],(ooo)[#2SOV]	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060AE3	4	H	8	13-Apr-1993	13-Apr-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060AE6	4	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV],(ooo)[#2SOV]	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060CC3	6	H	8	2-Jun-1993	2-Jun-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060CC6	6	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV],(ooo)[#2SOV]	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060CE3	6	H	8	2-Jun-1993	2-Jun-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DCDA	Conbraco	4060CE6	6	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV],(ooo)[#2SOV]	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060EC3	8	H	8	13-Apr-1993	13-Apr-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060EC6	8	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV],(ooo)[#2SOV]	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060EE3	8	H	8	13-Apr-1993	13-Apr-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060EE6	8	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV],(ooo)[#2SOV]	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060GC3	10	H	8	13-Apr-1993	13-Apr-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060GC6	10	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV],(ooo)[#2SOV]	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060GE3	10	H	8	12-Apr-1993	13-Mar-2005	(uu),cc,mm	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4060GE6	10	H	8	1-Feb-2000	1-Feb-2006	(mm)[#1SOV],(ooo)[#2SOV]	N	Conbraco 4010402 3/4" (H)
DCDA	Conbraco	4DCDA	4	H	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	4DCDA	4	VU	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	4DCDA6	4	H	9	10-Apr-2001	10-Apr-2004	(mm)[#1SOV],(nnn)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	4DCDA6	4	VU	9	10-Apr-2001	10-Apr-2004	(mm)[#1SOV],(nnn)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	4DCDA7	4	H	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	4DCDA7	4	VU	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	4DCDA8	4	H	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	4DCDA8	4	VU	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	4DCDAU	4	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	6DCDA	6	H	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	6DCDA	6	VU	9	16-Oct-2000	16-Oct-2006	(ll),mm	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	6DCDA6	6	H	9	10-Apr-2001	10-Apr-2004	(mm)[#1SOV],(nnn)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	6DCDA6	6	VU	9	10-Apr-2001	10-Apr-2004	(mm)[#1SOV],(nnn)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	6DCDA7	6	H	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	6DCDA7	6	VU	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	6DCDA8	6	H	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	6DCDA8	6	VU	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	6DCDAU	6	VUVD	9	10-Apr-2001	10-Apr-2004	(ll),mm	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	8DCDA	8	H	9	16-Jan-2003	16-Jan-2006	(mm),ll	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	8DCDA	8	VU	9	16-Jan-2003	16-Jan-2006	(mm),ll	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	8DCDA7	8	H	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	8DCDA7	8	VU	9	29-Sep-2004		(mm)[#1SOV],(qqq)[#2SOV]	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Conbraco	8DCDA8	8	H	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (H)
DCDA	Conbraco	8DCDA8	8	VU	9	29-Sep-2004		(ppp),qqq	N	Conbraco 1/2DC 1/2" (VU)
DCDA	Febco	806	4	H	6	4-Aug-1983	4-Aug-2004		Y	Febco 805Y 3/4" (H)
DCDA	Febco	806	6	H	6	13-May-1982	13-May-2006		Y	Febco 805Y 3/4" (H)
DCDA	Febco	806	8	H	6	13-May-1982	13-May-2006		Y	Febco 805Y 3/4" (H)
DCDA	Febco	806	10	H	6	13-May-1982	13-May-2006		Y	Febco 805Y 3/4" (H)
DCDA	Febco	806YD	3	H	8	26-Sep-1988	26-Sep-2006	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 805Y 3/4" (H)
DCDA	Febco	806YD	4	H	7	10-Jul-1987	10-Jul-2005	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 805Y 3/4" (H)
DCDA	Febco	806YD	6	H	7	10-Jul-1987	10-Jul-2005	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 805Y 3/4" (H)
DCDA	Febco	806YD	8	H	7	10-Jul-1987	10-Jul-2005	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 805Y 3/4" (H)
DCDA	Febco	806YD	10	H	7	10-Jul-1987	10-Jul-2005	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 805Y 3/4" (H)
DCDA	Febco	831H	4	H	9	24-Apr-2004		(int)	N	Febco 850B 3/4" (H)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DCDA	Febco	831H	4	VU	9	2-Jun-2004		(int)	N	Febco 850B 3/4" (H)
DCDA	Febco	856	2 1/2	H	8	19-Mar-1997	19-Mar-2006	(ff),mm,oo,pp,uu,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	856	2 1/2	VU	8	5-Jan-2000	5-Jan-2006	(ff),mm,oo,pp,uu,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (VU)
DCDA	Febco	856	3	H	8	19-Mar-1997	19-Mar-2006	(ff),mm,oo,pp,uu,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	856	3	VU	8	5-Jan-2000	5-Jan-2006	(ff),mm,oo,pp,uu,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (VU)
DCDA	Febco	856	4	H	8	4-May-1994	4-May-2006	(ff),mm,oo,pp,uu,nnn,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	856	4	VU	8	16-Apr-1996	16-Apr-2005	(ff),mm,oo,pp,uu,nnn,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (VU)
DCDA	Febco	856	6	H	8	4-May-1994	4-May-2006	(ff),mm,oo,pp,uu,nnn,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	856	6	VU	8	16-Apr-1996	16-Apr-2005	(ff),mm,oo,pp,uu,nnn,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (VU)
DCDA	Febco	856	8	H	8	4-Oct-1995	4-Oct-2004	(ff),mm,oo,pp,uu,nnn,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	856	8	VU	8	5-Jan-2000	5-Jan-2006	(ff),mm,oo,pp,uu,nnn,zzz,cccc,ffff,gggg	N	Febco 805YB 3/4" (VU)
DCDA	Febco	858	2	H	9	1-Aug-2006		bbb	N	Watts 007QT 1/2" (H)
DCDA	Febco	858	2	VU	9	1-Aug-2006		bbb	N	Watts 007QT 1/2" (VU)
DCDA	Febco	858	2 1/2	H	8	1-Aug-2006		(pp),gg,hh,ll,mm,oo,tt,uu,zz,fff	N	Watts 007M2QT 3/4" (H), Watts 007M1QT 3/4" (H)
DCDA	Febco	858	2 1/2	VU	8	1-Aug-2006		(pp),gg,hh,ll,mm,oo,tt,uu,zz,fff	N	Watts 007M2QT 3/4" (VU)
DCDA	Febco	858	3	H	8	1-Aug-2006		(pp),gg,hh,ll,mm,oo,tt,uu,zz,fff	N	Watts 007M2QT 3/4" (H), Watts 007M1QT 3/4" (H)
DCDA	Febco	876	2 1/2	VUVD	8	10-Mar-1995	10-Mar-2004	(ff),mm,oo,pp,uu,cccc,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876	3	VUVD	8	10-Mar-1995	10-Mar-2004	(ff),mm,oo,pp,uu,cccc,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876	4	VUVD	8	4-May-1994	4-May-2006	(ff),mm,oo,pp,uu,cccc,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876	6	VUVD	8	4-May-1994	4-May-2006	(ff),mm,oo,pp,uu,cccc,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876	8	VUVD	8	24-May-1995	24-May-2004	(ff),mm,oo,pp,uu,cccc,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876	10	VUVD	8	4-Oct-1996	4-Oct-2005	(ff),mm,oo,pp,uu,cccc,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	2 1/2	VUVD	8	8-Mar-1996	8-Mar-2005	(ff),ee,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	2 1/2	VUVU	8	8-Mar-1996	8-Mar-2005	(ff),ee,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	3	VUVD	8	8-Mar-1996	8-Mar-2005	(ff),ee,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	3	VUVU	8	8-Mar-1996	8-Mar-2005	(ff),ee,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	4	VUVD	8	8-Mar-1996	8-Mar-2005	(ff),ee,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	4	VUVU	8	8-Mar-1996	8-Mar-2005	(ff),ee,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	6	VUVD	8	8-Mar-1996	8-Mar-2005	(ff),ee,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	6	VUVU	8	8-Mar-1996	8-Mar-2005	(ff),ee,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	8	VUVD	8	6-Jan-1997	6-Jan-2006	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	8	VUVU	8	6-Jan-1997	6-Jan-2006	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	10	VUVD	8	11-Jul-1997	11-Jul-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Febco	876V	10	VUVU	8	11-Jul-1997	11-Jul-2006	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	Febco 805YB 3/4" (H)
DCDA	Watts	007DCDA	2	H	9	16-Jun-1997	16-Jun-2006	(bbb)	N	Watts 007QT 1/2" (H)
DCDA	Watts	007DCDA	2	VU	9	16-Jun-1997	16-Jun-2006	(bbb)	N	Watts 007QT 1/2" (VU)
DCDA	Watts	007DCDA	2 1/2	H	8	11-Oct-1993	11-Oct-2005	(pp),gg,hh,ll,mm,oo,tt,uu,zz,ffff,gggg	N	Watts 007M2QT 3/4" (H), Watts 007M1QT 3/4" (H)
DCDA	Watts	007DCDA	2 1/2	VU	8	27-Aug-1996	27-Aug-2005	(pp),gg,hh,ll,mm,oo,tt,uu,zz,ffff,gggg	N	Watts 007M2QT 3/4" (VU)
DCDA	Watts	007DCDA	3	H	8	19-Sep-1992	19-Sep-2004	(pp),hh,mm,uu,zz,ffff,gggg	N	Watts 007M2QT 3/4" (H), Watts 007M1QT 3/4" (H)
DCDA	Watts	007DCDA	4	H	8	1-Feb-1995	1-Feb-2004	(oo),gg,hh,pp,tt,uu	Y	Watts 007M1QT 3/4" (H)
DCDA	Watts	007DCDA	6	H	8	1-Feb-1995	1-Feb-2004	(oo),gg,hh,pp,tt,uu	Y	Watts 007M1QT 3/4" (H)
DCDA	Watts	709DCDA	3	H	6	19-Apr-1987	19-Apr-2005	(pp),hh,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (H), Watts 007M1QT 3/4" (H), Watts 709QT 3/4" (H)
DCDA	Watts	709DCDA	4	H	6	27-Jul-1987	27-Jul-2005	(pp),hh,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (H), Watts 007M1QT 3/4" (H), Watts 709QT 3/4" (H)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DCDA	Watts	709DCDA	4	VU	8	27-Aug-1996	27-Aug-2005	(pp),hh,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (VU), Watts 007M2QT 3/4" (VU)
DCDA	Watts	709DCDA	6	H	6	27-Jul-1987	27-Jul-2005	(pp),hh,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (H), Watts 007M1QT 3/4" (H), Watts 709QT 3/4" (H)
DCDA	Watts	709DCDA	6	VU	8	5-Dec-1996	5-Dec-2005	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (VU)
DCDA	Watts	709DCDA	8	H	6	19-Apr-1987	19-Apr-2005	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (H), Watts 007M1QT 3/4" (H), Watts 709QT 3/4" (H)
DCDA	Watts	709DCDA	8	VU	8	5-Dec-1996	5-Dec-2005	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (VU)
DCDA	Watts	709DCDA	10	H	6	27-Jul-1987	27-Jul-2005	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (H), Watts 007M1QT 3/4" (H), Watts 709QT 3/4" (H)
DCDA	Watts	709DCDA	10	VU	8	5-Dec-1996	5-Dec-2005	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 007QT 1/2" (VU)
DCDA	Watts	757aDCDABF	2 1/2	H	9	6-Nov-2003		(yyy),ffff,gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757aDCDABF	2 1/2	VU	9	6-Nov-2003		(yyy),ffff,gggg	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	757aDCDABF	3	H	9	6-Nov-2003		(yyy),ffff,gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757aDCDABF	3	VU	9	6-Nov-2003		(yyy),ffff,gggg	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	757aDCDABF	4	H	9	6-Nov-2003		(yyy),ffff,gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757aDCDABF	4	VU	9	6-Nov-2003		(yyy),ffff,gggg	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	757aDCDABF	6	H	9	3-Nov-2004		(yyy),ffff,gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757aDCDABF	6	VU	9	18-Jan-2005		(yyy),ffff,gggg	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	757aDCDAGV	2 1/2	H	9	6-Nov-2003		(zzz),ffff,gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757aDCDAGV	2 1/2	VU	9	6-Nov-2003		(zzz),ffff,gggg	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	757aDCDAGV	3	H	9	6-Nov-2003		(zzz),ffff,gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757aDCDAGV	3	VU	9	6-Nov-2003		(zzz),ffff,gggg	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	757aDCDAGV	4	H	9	6-Nov-2003		(zzz),ffff,gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757aDCDAGV	4	VU	9	6-Nov-2003		(zzz),ffff,gggg	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	757aDCDAGV	6	H	9	18-Jan-2005		(zzz),ffff,gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757aDCDAGV	6	VU	9	18-Jan-2005		(zzz),ffff,gggg	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	757DCDABF	2 1/2	H	9	4-Oct-2005		(yyy),gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757DCDABF	2 1/2	VU	9	4-Oct-2005		(yyy),gggg	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	757DCDABF	3	H	9	4-Oct-2005		(yyy),gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757DCDABF	3	VU	9	4-Oct-2005		(yyy),gggg	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	757DCDABF	4	H	9	4-Oct-2005		(yyy)	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757DCDABF	4	VU	9	4-Oct-2005		(yyy),gggg	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	757DCDAGV	2 1/2	H	9	4-Oct-2005		(zzz),gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757DCDAGV	2 1/2	VU	9	4-Oct-2005		(zzz),gggg	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	757DCDAGV	3	H	9	4-Oct-2005		(zzz),gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757DCDAGV	3	VU	9	4-Oct-2005		(zzz),gggg	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	757DCDAGV	4	H	9	4-Oct-2005		(zzz),gggg	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	757DCDAGV	4	VU	9	4-Oct-2005		(zzz),gggg	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	767aDCDABF	2 1/2	H	9	6-Nov-2003		(yyy),fff	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767aDCDABF	2 1/2	VU	9	6-Nov-2003		(yyy),fff	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	767aDCDABF	3	H	9	6-Nov-2003		(yyy),fff	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767aDCDABF	3	VU	9	6-Nov-2003		(yyy),fff	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	767aDCDABF	4	H	9	30-Aug-2006		(yyy),fff	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	767aDCDABF	4	VU	9	18-Jan-2005		(yyy),fff	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	767aDCDAGV	2 1/2	H	9	6-Nov-2003		(zzz),fff	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767aDCDAGV	2 1/2	VU	9	6-Nov-2003		(zzz),fff	N	Watts 007M3QT 3/4" (VU)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
DCDA	Watts	767aDCDAGV	3	H	9	6-Nov-2003		(zzz),fff	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767aDCDAGV	3	VU	9	6-Nov-2003		(zzz),fff	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	767aDCDAGV	4	H	9	6-Nov-2003		(zzz),fff	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767aDCDAGV	4	VU	9	18-Jan-2005		(zzz),fff	N	Watts 007M3QT 3/4" (VU)
DCDA	Watts	767DCDABF	2 1/2	H	9	4-Oct-2005		(yyy)	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767DCDABF	2 1/2	VU	9	4-Oct-2005		(yyy)	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	767DCDABF	3	H	9	4-Oct-2005		(yyy)	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767DCDABF	3	VU	9	4-Oct-2005		(yyy)	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	767DCDAGV	2 1/2	H	9	4-Oct-2005		(zzz)	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767DCDAGV	2 1/2	VU	9	4-Oct-2005		(zzz)	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	767DCDAGV	3	H	9	4-Oct-2005		(zzz)	N	Watts 007M3QT 3/4" (H)
DCDA	Watts	767DCDAGV	3	VU	9	4-Oct-2005		(zzz)	N	Watts 007M3QT 3/4" (V)
DCDA	Watts	770DCDA	4	H	8	20-May-1992	20-May-2004	(pp),hh,mm,uu,zz	Y	Watts 007M1QT 3/4" (H)
DCDA	Watts	770DCDA	8	H	8	13-Jan-1993	13-Jan-2005	(oo),gg,hh,ll,mm,pp,tt,uu	Y	Watts 007M1QT 3/4" (H)
DCDA	Watts	772DCDA	4	H	8	1-Aug-1992	1-Aug-2004	(oo)	Y	Watts 007M1QT 3/4" (H)
DCDA	Watts	772DCDA	10	H	8	13-Jan-1993	13-Jan-2005	(oo)	Y	Watts 007M1QT 3/4" (H)
DCDA	Watts	774DCDA	2 1/2	H	8	24-May-1995	24-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts 007M2QT 3/4: (H), Ames 2000B 3/4" (H)
DCDA	Watts	774DCDA	3	H	8	24-May-1995	24-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts 007M2QT 3/4: (H), Ames 2000B 3/4" (H)
DCDA	Watts	774DCDA	4	H	8	24-May-1995	24-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts 007M2QT 3/4: (H), Ames 2000B 3/4" (H)
DCDA	Watts	774DCDA	6	H	8	9-Sep-1992	9-Sep-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts 007M1QT 3/4" (H)
DCDA	Watts	774DCDA	8	H	8	16-Sep-1996	16-Sep-2005	(mm),ee,ff,gg,hh,ll,oo,pp,tt,uu,ccc,ddd,fff,gggg	N	Watts 007M2QT 3/4: (H), Ames 2000B 3/4" (H)
DCDA	Watts	774DCDA	10	H	8	16-Feb-2001	16-Feb-2004	(ll),mm,fff,gggg	N	Watts 007M2QT 3/4: (H), Ames 2000B 3/4" (H)
DCDA	Watts	774XDCDA	2 1/2	H	8	10-Sep-1996	10-Sep-2005	(mm),ee,ff,gg,hh,ll,oo,pp,tt,uu,ccc,ddd,fff,gggg	N	Watts 007M2QT 3/4: (H), Ames 2000B 3/4" (H)
DCDA	Watts	774XDCDA	6	H	8	24-May-1995	24-May-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,uu,ccc,ddd,fff,gggg	N	Watts 007M2QT 3/4: (H), Ames 2000B 3/4" (H)
DCDA	Watts	774XDCDA	8	H	8	9-Sep-1992	9-Sep-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,fff,gggg	N	Watts 007M1QT 3/4" (H)
DCDA	Wilkins	350ADA	2 1/2	H	9	22-Jun-2005		(qqq),ttt,yyy,zzz	N	Wilkins 3/4" Model 950XLD (H & VU) DC
DCDA	Wilkins	350ADA	2 1/2	VU	9	22-Jun-2005		(qqq),ttt,yyy,zzz	N	Wilkins 3/4" Model 950XLD (H & VU) DC
DCDA	Wilkins	350ADA	3	H	9	22-Jun-2005		(qqq),ttt,yyy,zzz	N	Wilkins 3/4" Model 950XLD (H & VU) DC
DCDA	Wilkins	350ADA	3	VU	9	22-Jun-2005		(qqq),ttt,yyy,zzz	N	Wilkins 3/4" Model 950XLD (H & VU) DC
DCDA	Wilkins	350ADA	4	H	9	16-Mar-2004		(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4 (H)
DCDA	Wilkins	350ADA	4	VU	9	16-Mar-2004		(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4 (VU)
DCDA	Wilkins	350ADA	6	H	9	25-Nov-2003		(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350ADA	6	VU	9	25-Nov-2003		(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4" (VU)
DCDA	Wilkins	350ADA	8	H	9	12-Feb-2004		(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350ADA	8	VU	9	12-Feb-2004		(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4" (VU)
DCDA	Wilkins	350ADA	10	H	9	6-Apr-2006		(qqq), ttt	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350ADA	10	VU	9	6-Apr-2006		(qqq), ttt	N	Wilkins 950XLD 3/4" (VU)
DCDA	Wilkins	350DA	2 1/2	H	9	3-Apr-2002	3-Apr-2005	(hh),ff,mm,uu,zz	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350DA	2 1/2	VU	9	8-Oct-2002	8-Oct-2005	(hh),ff,mm,uu,zz	N	Wilkins 950XLD 3/4" (VU)
DCDA	Wilkins	350DA	3	H	9	3-Apr-2002	3-Apr-2005	(hh),ff,mm,uu,zz	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350DA	3	VU	9	8-Oct-2002	8-Oct-2005	(hh),ff,mm,uu,zz	N	Wilkins 950XLD 3/4" (VU)
DCDA	Wilkins	350DA	4	H	9	15-Sep-1999	15-Sep-2005	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350DA	4	VU	9	9-Sep-2000	9-Sep-2006	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 950XLD 3/4" (VU)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
DCDA	Wilkins	350DA	6	H	9	18-Oct-1999	18-Oct-2005	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350DA	6	VU	9	5-Jan-2000	5-Jan-2006	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 950XLD 3/4" (VU)
DCDA	Wilkins	350DA	8	H	9	3-Jul-2002	3-Jul-2005	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350DA	8	VU	9	16-Jan-2003	16-Jan-2006	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 950XLD 3/4" (VU)
DCDA	Wilkins	350DA	10	H	9	28-Aug-2002	28-Aug-2005	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	350DA	10	VU	9	14-Mar-2003	14-Mar-2006	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 950XLD 3/4" (VU)
DCDA	Wilkins	450DA	4	VUVD	9	12-Apr-2000	12-Apr-2006	(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	450DA	6	VUVD	9	24-May-2000	24-May-2006	(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	450DA	8	VUVD	9	3-Aug-2004		(qqq),ttt,www,yyy,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	450DA	10	VUVD	9	3-Aug-2004		(qqq),ttt,www,zzz,eeee	N	Wilkins 950XLD 3/4" (H)
DCDA	Wilkins	950DA	2 1/2	H	8	2-Jan-1994	2-Jan-2006	(hh),ff,mm,uu,zz	N	Wilkins 950XL 3/4" (H), Wilkins 950 3/4" (H)
DCDA	Wilkins	950DA	2 1/2	VU	8	12-Dec-1996	12-Dec-2005	(hh),ff,mm,uu,zz	N	Wilkins 950XL 3/4" (VU)
DCDA	Wilkins	950DA	3	H	8	2-Jan-1994	2-Jan-2006	(hh),ff,mm,uu,zz	N	Wilkins 950XL 3/4" (H), Wilkins 950 3/4" (H)
DCDA	Wilkins	950DA	3	VU	8	12-Dec-1996	12-Dec-2005	(hh),ff,mm,uu,zz	N	Wilkins 950XL 3/4" (VU)
DCDA	Wilkins	950DA	4	H	8	9-Jun-1993	9-Jun-2005	(hh),ff,mm,uu,zz,qqq	N	Wilkins 950XL 3/4" (H), Wilkins 950 3/4" (H)
DCDA	Wilkins	950DA	4	VU	8	12-Dec-1996	12-Dec-2005	(hh),ff,mm,uu,zz,qqq	N	Wilkins 950XL 3/4" (VU)
DCDA	Wilkins	950DA	6	H	8	9-Jun-1993	9-Jun-2005	(hh),ff,mm,uu,zz,qqq	N	Wilkins 950XL 3/4" (H), Wilkins 950 3/4" (H)
DCDA	Wilkins	950DA	6	VU	8	12-Dec-1996	12-Dec-2005	(hh),ff,mm,uu,zz,qqq	N	Wilkins 950XL 3/4" (VU)
DCDA	Wilkins	950DA	8	H	8	9-Jun-1993	9-Jun-2005	(hh),ff,mm,uu,zz	N	Wilkins 950XL 3/4" (H), Wilkins 950 3/4" (H)
DCDA	Wilkins	950DA	8	VU	8	12-Dec-1996	12-Dec-2005	(hh),ff,mm,uu,zz	N	Wilkins 950XL 3/4" (VU)
DCDA	Wilkins	950DA	10	H	8	23-Jun-1994	23-Jun-2006	(hh),ff,mm,uu,zz	N	Wilkins 950XL 3/4" (H), Wilkins 950 3/4" (H)
DCDA	Wilkins	DCDA	2 1/2	H	7	5-Mar-1987	5-Mar-2005	(hh),ff,mm,uu,zz	Y	Wilkins 550A 3/4" (H)
DCDA	Wilkins	DCDA	3	H	7	5-Mar-1987	5-Mar-2005	(hh),ff,mm,uu,zz	Y	Wilkins 550A 3/4" (H)
DCDA	Wilkins	DCDA	4	H	7	18-May-1988	18-May-2006	(hh),ff,mm,uu,zz	Y	Wilkins 550A 3/4" (H)
DCDA	Wilkins	DCDA	6	H	7	2-Jun-1988	2-Jun-2006	(hh),ff,mm,uu,zz	Y	Wilkins 550A 3/4" (H)
PVB	Ames	A200	3/4	VUH	8	6-Apr-1993	6-Apr-2005	(vv), xx	N	
PVB	Ames	A200	1	VUH	8	25-May-1993	25-May-2005	(vv), xx	N	
PVB	Ames	A200	1 1/2	VUH	8	21-Jun-1993	21-Jun-2005	(vv), xx	N	
PVB	Ames	A200	2	VUH	8	21-Jun-1993	21-Jun-2005	(vv), xx	N	
PVB	Buckner	24199	1/2	VUH	8	10-Dec-1991	10-Dec-2003	(ii)	Y	
PVB	Buckner	24199/25	1/2	VUH	8	10-Dec-1991	10-Dec-2003	(ii)	Y	
PVB	Buckner	24200	3/4	VUH	8	10-Dec-1991	10-Dec-2003	(ii)	Y	
PVB	Buckner	24200/25	3/4	VUH	8	10-Dec-1991	10-Dec-2003	(ii)	Y	
PVB	Buckner	24201	1	VUH	8	10-Dec-1991	10-Dec-2003	(ii)	Y	
PVB	Buckner	24201/25	1	VUH	8	10-Dec-1991	10-Dec-2003	(ii)	Y	
PVB	Buckner	24202	1 1/4	VUH	8	9-Sep-1992	9-Sep-2004	(ii)	Y	
PVB	Buckner	24202/25	1 1/4	VUH	8	9-Sep-1992	9-Sep-2004	(ii)	Y	
PVB	Buckner	24203	1 1/2	VUH	8	9-Sep-1992	9-Sep-2004	(ii)	Y	
PVB	Buckner	24203/25	1 1/2	VUH	8	9-Sep-1992	9-Sep-2004	(ii)	Y	
PVB	Buckner	24204	2	VUH	8	9-Sep-1992	9-Sep-2004	(ii)	Y	
PVB	Buckner	24204/25	2	VUH	8	9-Sep-1992	9-Sep-2004	(ii)	Y	
PVB	Conbraco	4050302	1/2	VUH	8	6-Sep-1991	6-Sep-2006	(dd)	N	
PVB	Conbraco	4050402	3/4	VUH	8	6-Sep-1991	6-Sep-2006	(dd)	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
PVB	Conbraco	4050502	1	VUH	8	6-Sep-1991	6-Sep-2006	(dd)	N	
PVB	Conbraco	4050602	1 1/4	VUH	8	1-Dec-1993	1-Dec-2005	(dd)	N	
PVB	Conbraco	4050702	1 1/2	VUH	8	1-Dec-1993	1-Dec-2005	(dd)	N	
PVB	Conbraco	4050802	2	VUH	8	1-Dec-1993	1-Dec-2005	(dd)	N	
PVB	Conbraco	PVB	1/2	VUH	9	23-Sep-1999	23-Sep-2005	(dd)	N	
PVB	Conbraco	PVB	3/4	VUH	9	23-Sep-1999	23-Sep-2005	(dd)	N	
PVB	Conbraco	PVB	1	VUH	9	23-Sep-1999	23-Sep-2005	(dd)	N	
PVB	Conbraco	PVB	1 1/4	VUH	9	7-Oct-2002	7-Oct-2005	(dd)	N	
PVB	Conbraco	PVB	1 1/2	VUH	9	7-Oct-2002	7-Oct-2005	(dd)	N	
PVB	Conbraco	PVB	2	VUH	9	18-Jun-2003	18-Jun-2006	(dd)	N	
PVB	Febco	745	3/4	VUH	6	10-May-1983	10-May-2004	(ii),fff,jjj,ooo	N	
PVB	Febco	745	1	VUH	6	10-May-1983	10-May-2004	(ii),fff,jjj,ooo	N	
PVB	Febco	765	1/2	VUH	5	26-Mar-1974	1-Jul-2004	(ii),fff,jjj,ooo	N	
PVB	Febco	765	3/4	VUH	5	26-Mar-1974	1-Jul-2004	(ii),fff,jjj,ooo,xxx	N	
PVB	Febco	765	1	VUH	5	26-Mar-1974	1-Jul-2004	(ii),fff,jjj,ooo,xxx	N	
PVB	Febco	765	1 1/4	VUH	5	26-Mar-1974	1-Jul-2004	(ii),fff,jjj,ooo	N	
PVB	Febco	765	1 1/2	VUH	5	26-Mar-1974	1-Jul-2004	(ii),fff,jjj,ooo,xxx	N	
PVB	Febco	765	2	VUH	5	26-Mar-1974	1-Jul-2004	(ii),fff,ooo,xxx	N	
PVB	Febco	766	1	VUH	9	31-Aug-1999	31-Aug-2005	(fff),ii,jjj,ooo	N	
PVB	Febco	767-FR	1/2	VUH	9	1-Aug-2006		(vv), xx	N	
PVB	Febco	767-FR	3/4	VUH	9	1-Aug-2006		(vv), xx	N	
PVB	Febco	767-FR	1	VUH	9	1-Aug-2006		(vv), xx	N	
PVB	Febco	767-FR	1 1/4	VUH	9	1-Aug-2006		(vv), xx	N	
PVB	Febco	767-FR	1 1/2	VUH	9	1-Aug-2006		(vv), xx	N	
PVB	Febco	767-FR	2	VUH	9	1-Aug-2006		(vv), xx	N	
PVB	Flomatic	PVB	3/4	VUH	9	21-Nov-1997	21-Nov-2003	(ii)	N	
PVB	Flomatic	PVB	1	VUH	9	21-Nov-1997	21-Nov-2003	(ii)	N	
PVB	Neptune									
PVB	RainBird									
PVB	Watts	800CMQT	1/2	VUH	8	18-Jul-1989	18-Jul-2004	(vv), xx	N	
PVB	Watts	800CMQT	3/4	VUH	8	18-Jul-1989	18-Jul-2004	(vv), xx	N	
PVB	Watts	800M2QT	1/2	VUH	8	9-Jul-1991	9-Jul-2006	(vv), xx	Y	
PVB	Watts	800M2QT	3/4	VUH	8	9-Jul-1991	9-Jul-2006	(vv), xx	Y	
PVB	Watts	800M2QT	1	VUH	8	9-Jul-1991	9-Jul-2006	(vv), xx	Y	
PVB	Watts	800M2QT	1 1/4	VUH	8	25-Mar-1993	25-Mar-2005	(vv), xx	Y	
PVB	Watts	800M2QT	1 1/2	VUH	8	25-Mar-1993	25-Mar-2005	(vv), xx	Y	
PVB	Watts	800M2QT	2	VUH	8	25-Mar-1993	25-Mar-2005	(vv), xx	Y	
PVB	Watts	800M3QT	1/2	VUH	8	24-Feb-1992	24-Feb-2004	(vv), xx	Y	
PVB	Watts	800M3QT	3/4	VUH	8	24-Feb-1992	24-Feb-2004	(vv), xx	Y	
PVB	Watts	800M4FR	1/2	VUH	9	12-May-1998	12-May-2004	(vv), xx	N	
PVB	Watts	800M4FR	3/4	VUH	9	12-May-1998	12-May-2004	(vv), xx	N	
PVB	Watts	800M4FR	1	VUH	9	1-Sep-1995	1-Sep-2004	(vv), xx	N	
PVB	Watts	800M4FR	1 1/4	VUH	9	13-May-1997	13-May-2006	(vv), xx	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
PVB	Watts	800M4FR	1 1/2	VUH	9	13-May-1997	13-May-2006	(vv),xx	N	
PVB	Watts	800M4FR	2	VUH	9	13-May-1997	13-May-2006	(vv),xx	N	
PVB	Watts	800M4QT	1/2	VUH	8	6-Sep-1993	6-Sep-2005	(vv),xx	N	
PVB	Watts	800M4QT	3/4	VUH	8	6-Apr-1993	6-Apr-2005	(vv),xx	N	
PVB	Watts	800M4QT	1	VUH	8	25-May-1993	25-May-2005	(vv),xx	N	
PVB	Watts	800M4QT	1 1/4	VUH	8	24-May-1994	24-May-2006	(vv),xx	N	
PVB	Watts	800M4QT	1 1/2	VUH	8	21-Jun-1993	21-Jun-2005	(vv),xx	N	
PVB	Watts	800M4QT	2	VUH	8	21-Jun-1993	21-Jun-2005	(vv),xx	N	
PVB	Watts	800MQT	1/2	VUH	8	18-Jul-1989	18-Jul-2004	(vv),xx	N	
PVB	Watts	800MQT	3/4	VUH	8	18-Jul-1989	18-Jul-2004	(vv),xx	N	
PVB	Watts	800QT	3/4	VUH	5	14-Feb-1978	14-Feb-2005	(vv),xx	Y	
PVB	Watts	800QT	1	VUH	5	14-Feb-1978	14-Feb-2005	(vv),xx	Y	
PVB	Watts	800QT	1 1/4	VUH	5	14-Feb-1978	14-Feb-2005	(vv),xx	Y	
PVB	Watts	800QT	1 1/2	VUH	5	14-Feb-1978	14-Feb-2005	(vv),xx	Y	
PVB	Watts	800QT	2	VUH	5	14-Feb-1978	14-Feb-2005	(vv),xx	Y	
PVB	Wilkins	420	1/2	VUH	9	17-Jul-1999	17-Jul-2005	(ii),ooo	N	
PVB	Wilkins	420	3/4	VUH	9	17-Jul-1999	17-Jul-2005	(ii),ooo	N	
PVB	Wilkins	420	1	VUH	9	29-Sep-2000	29-Sep-2006	(ii),ooo	N	
PVB	Wilkins	720A	1/2	VUH	5	28-Aug-1978	28-Aug-2005	(ii),ooo	N	
PVB	Wilkins	720A	3/4	VUH	5	28-Aug-1978	28-Aug-2005	(ii),ooo	N	
PVB	Wilkins	720A	1	VUH	5	28-Aug-1978	28-Aug-2005	(ii),ooo	N	
PVB	Wilkins	720A	1 1/4	VUH	5	28-Aug-1978	28-Aug-2005	(ii),ooo	N	
PVB	Wilkins	720A	1 1/2	VUH	5	28-Aug-1978	28-Aug-2005	(ii),ooo	N	
PVB	Wilkins	720A	2	VUH	5	28-Aug-1978	28-Aug-2005	(ii),ooo	N	
RP	Ames	4000B	1/2	H	9	10-Sep-1996	10-Sep-2005	(vv),xx	N	
RP	Ames	4000B	3/4	H	8	31-Oct-1992	31-Oct-2004	(vv),xx	N	
RP	Ames	4000B	1	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	N	
RP	Ames	4000B	1 1/4	H	8	24-Aug-1993	24-Aug-2005	(vv),xx	N	
RP	Ames	4000B	1 1/2	H	8	24-Aug-1993	24-Aug-2005	(vv),xx	N	
RP	Ames	4000B	2	H	9	10-Sep-1996	10-Sep-2005	(vv),xx	N	
RP	Ames	4000BM2	1	H	9	18-May-1998	18-May-2004	(vv),xx	N	
RP	Ames	4000BM3	3/4	H	9	27-Mar-2000	27-Mar-2006	(vv),xx	N	
RP	Ames	4000CIV	2 1/2	H	7	7-Jul-2000	7-Jul-2006	(oo),gg,hh,ll,mm,pp,tt,uu	N	
RP	Ames	4000CIV	3	H	7	7-Jul-2000	7-Jul-2006	(oo),gg,hh,ll,mm,pp,tt,uu	N	
RP	Ames	4000CIV	4	H	6	19-Jun-2000	19-Jun-2006	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
RP	Ames	4000CIV	6	H	6	19-Jun-2000	19-Jun-2006	(oo),gg,hh,ll,mm,pp,tt,uu,eee	N	
RP	Ames	4000CIV	8	H	8	19-Jun-2000	19-Jun-2006	(oo),gg,hh,ll,mm,pp,tt,uu	N	
RP	Ames	4000CIV	10	H	8	19-Jun-2000	19-Jun-2006	(oo),gg,hh,ll,mm,pp,tt,uu	N	
RP	Ames	4000RP	4	H	7	13-Oct-1987	13-Oct-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Ames	4000RP	6	H	7	13-Oct-1987	13-Oct-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Ames	4000RP	8	H	7	13-Oct-1987	13-Oct-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Ames	4000RP	10	H	7	13-Oct-1987	13-Oct-2005	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Ames	4000SS	2 1/2	H	8	15-Apr-1994	15-Apr-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Ames	4000SS	3	H	8	15-Apr-1994	15-Apr-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Ames	4000SS	4	H	8	15-Apr-1994	15-Apr-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Ames	4000SS	6	H	8	22-Sep-1997	22-Sep-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Ames	400B	3/4	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B	3/4	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	400B	1	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B	1	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	400B	1 1/4	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B	1 1/4	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	400B	1 1/2	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B	1 1/2	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	400B	2	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B	2	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	400B-A	3/4	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B-A	1	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B-A	1 1/4	VUVD	9	5-Sep-2006		(vvv), hhhh	N	
RP	Ames	400B-A	1 1/2	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B-A	2	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B-Z	3/4	VUVU	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B-Z	1	VUVU	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B-Z	1 1/4	VUVU	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B-Z	1 1/2	VUVU	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	400B-Z	2	VUVU	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	Colt 400	2 1/2	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Colt 400	3	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Colt 400	4	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Colt 400	6	H	9	29-Sep-2004		(ppp),qqq,aaaa,bbbb	N	
RP	Ames	Colt 400N	2 1/2	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,,yyy,zzz,aaaa,bbbb,ffff	N	
RP	Ames	Colt 400N	3	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Colt 400N	4	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Colt 400Z	2 1/2	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Colt 400Z	3	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Colt 400Z	4	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Maxim 400	2 1/2	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Maxim 400	3	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Maxim 400	4	H	9	18-Jan-2005		(ppp), qqg, aaaa, bbbb	N	
RP	Ames	Maxim 400N	2 1/2	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Maxim 400N	3	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Maxim 400Z	2 1/2	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	Maxim 400Z	3	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Ames	U400B	3/4	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	U400B	1	H	9	20-Jun-2006		(vvv), hhhh	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Ames	U400B	1	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	U400B	1 1/4	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	U400B	1 1/4	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	U400B	1 1/2	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	U400B	1 1/2	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	U400B	2	H	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	U400B	2	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Ames	U400B-A	3/4	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	U400B-A	1	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	U400B-A	1 1/4	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	U400B-A	1 1/2	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Ames	U400B-A	2	VUVD	9	20-Jun-2006		(vvv), hhhh	N	
RP	Buckner	24000	3/4	H	8	14-Mar-1994	14-Mar-2006	(ii)	Y	
RP	Buckner	24000/25	3/4	H	8	14-Mar-1994	14-Mar-2006	(ii)	Y	
RP	Buckner	24001	1	H	8	14-Mar-1994	14-Mar-2006	(ii)	Y	
RP	Buckner	24001/25	1	H	8	14-Mar-1994	14-Mar-2006	(ii)	Y	
RP	Buckner	24002	1 1/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	Y	
RP	Buckner	24002/25	1 1/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	Y	
RP	Buckner	24003	1 1/2	H	8	18-Jul-1991	18-Jul-2006	(ii)	Y	
RP	Buckner	24003/25	1 1/2	H	8	18-Jul-1991	18-Jul-2006	(ii)	Y	
RP	Buckner	24004	2	H	8	18-Jul-1991	18-Jul-2006	(ii)	Y	
RP	Buckner	24004/25	2	H	8	18-Jul-1991	18-Jul-2006	(ii)	Y	
RP	Cla-Val	RP2	3/4	H	4	6-Feb-1974	18-Mar-2004	(nn),dd	Y	
RP	Cla-Val	RP2	1	H	4	6-Feb-1974	18-Mar-2004	(nn),dd	Y	
RP	Cla-Val	RP2	1 1/4	H	5	13-Aug-1976	5-Oct-2006	(nn),dd	Y	
RP	Cla-Val	RP2	1 1/2	H	5	13-Aug-1976	5-Oct-2006	(nn),dd	Y	
RP	Cla-Val	RP4	2	H	8	22-Jun-1989	22-Jun-2004	(nn)	Y	
RP	Cla-Val	RP4	2 1/2	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
RP	Cla-Val	RP4	3	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
RP	Cla-Val	RP4	4	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
RP	Cla-Val	RP4	6	H	8	7-Aug-1987	7-Aug-2005	(gg),hh,qq,rr	N	
RP	Cla-Val	RP4	8	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
RP	Cla-Val	RP4	10	H	8	22-Jun-1989	22-Jun-2004	(gg),hh,qq,rr	N	
RP	Cla-Val	RP4V	4	VUVU	8	15-Mar-1990	15-Mar-2005	(gg),hh,qq,rr	N	
RP	Conbraco	4020002	3	H	8	8-Apr-1991	8-Apr-2006	(tt),bb,ee,ll	N	
RP	Conbraco	4020003	3	H	8	8-Apr-1991	8-Apr-2006	(uu),cc,mm	N	
RP	Conbraco	4020005	3	H	8	8-Dec-1998	8-Dec-2004	(mmm)	N	
RP	Conbraco	4020102	1/4	H	8	3-May-1991	3-May-2006	(dd)	N	
RP	Conbraco	40201A2	1/4	H	8	19-Apr-1996	19-Apr-2005	(dd)	N	
RP	Conbraco	40201T2	1/4	H	8	16-Sep-1998	16-Sep-2004	(dd)	N	
RP	Conbraco	40201T2S	1/4	H	8	19-Apr-1996	19-Apr-2005	(uuu)	N	
RP	Conbraco	4020202	3/8	H	8	3-May-1991	3-May-2006	(dd)	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Conbraco	40202A2	3/8	H	8	19-Apr-1996	19-Apr-2005	(dd)	N	
RP	Conbraco	40202T2	3/8	H	8	16-Sep-1998	16-Sep-2004	(dd)	N	
RP	Conbraco	40202T2S	3/8	H	8	19-Apr-1996	19-Apr-2005	(uuu)	N	
RP	Conbraco	4020302	1/2	H	8	3-May-1991	3-May-2005	(dd)	N	
RP	Conbraco	40203A2	1/2	H	8	19-Apr-1996	19-Apr-2005	(dd)	N	
RP	Conbraco	40203T2	1/2	H	8	16-Sep-1998	16-Sep-2004	(dd)	N	
RP	Conbraco	40203T2S	1/2	H	8	19-Apr-1996	19-Apr-2005	(dd)	N	
RP	Conbraco	4020402	3/4	H	8	8-May-1989	8-May-2004	(dd)	N	
RP	Conbraco	40204A2	3/4	H	8	27-Nov-1991	27-Nov-2003	(dd)	N	
RP	Conbraco	40204T2	3/4	H	8	16-Sep-1998	16-Sep-2004	(dd)	N	
RP	Conbraco	40204T2S	3/4	H	8	16-Aug-1994	16-Aug-2006	(uuu)	N	
RP	Conbraco	40204T2U	3/4	VUVD	8	6-Nov-1992	6-Nov-2004	(dd)	N	
RP	Conbraco	40204T2Z	3/4	VUVU	8	6-Nov-1992	6-Nov-2004	(dd)	N	
RP	Conbraco	40204TC2	3/4	H	8	30-Nov-1998	30-Nov-2004	(dd)	N	
RP	Conbraco	40204TCU	3/4	VUVD	8	30-Nov-1998	30-Nov-2004	(dd)	N	
RP	Conbraco	4020502	1	H	8	8-May-1989	8-May-2004	(dd)	N	
RP	Conbraco	40205A2	1	H	8	27-Nov-1991	27-Nov-2003	(dd)	N	
RP	Conbraco	40205T2	1	H	8	16-Sep-1998	16-Sep-2004	(dd)	N	
RP	Conbraco	40205T2S	1	H	8	16-Aug-1994	16-Aug-2006	(uuu)	N	
RP	Conbraco	40205T2U	1	VUVD	8	15-Sep-1993	15-Sep-2005	(dd)	N	
RP	Conbraco	40205T2Z	1	VUVU	8	15-Sep-1993	15-Sep-2005	(dd)	N	
RP	Conbraco	40205TC2	1	H	8	30-Nov-1998	30-Nov-2004	(dd)	N	
RP	Conbraco	40205TCU	1	VUVD	8	30-Nov-1998	30-Nov-2004	(dd)	N	
RP	Conbraco	4020602	1 1/4	H	8	6-Apr-1992	6-Apr-2004	(dd)	N	
RP	Conbraco	40206A2	1 1/4	H	8	21-Jun-1993	21-Jun-2005	(dd)	N	
RP	Conbraco	40206T2	1 1/4	H	8	16-Sep-1998	16-Sep-2004	(dd)	N	
RP	Conbraco	40206T2U	1 1/4	VUVD	8	2-Feb-1995	2-Feb-2004	(dd)	N	
RP	Conbraco	40206T2Z	1 1/4	VUVU	8	2-Feb-1995	2-Feb-2004	(dd)	N	
RP	Conbraco	4020702	1 1/2	H	8	17-Mar-1989	17-Mar-2004	(dd)	N	
RP	Conbraco	40207A2	1 1/2	H	8	16-Sep-1992	16-Sep-2004	(dd)	N	
RP	Conbraco	40207T2	1 1/2	H	8	16-Sep-1998	16-Sep-2004	(dd)	N	
RP	Conbraco	40207T2U	1 1/2	VUVD	8	2-Feb-1995	2-Feb-2004	(dd)	N	
RP	Conbraco	40207T2Z	1 1/2	VUVU	8	2-Feb-1995	2-Feb-2004	(dd)	N	
RP	Conbraco	4020802	2	H	8	17-Mar-1989	17-Mar-2004	(dd)	N	
RP	Conbraco	40208A2	2	H	8	16-Sep-1992	16-Sep-2004	(dd)	N	
RP	Conbraco	40208A4	2	H	8	24-May-2000	24-May-2006	(rrr)	N	
RP	Conbraco	40208T2	2	H	8	16-Sep-1998	16-Sep-2004	(dd)	N	
RP	Conbraco	40208T2U	2	VUVD	8	2-Feb-1995	2-Feb-2004	(dd)	N	
RP	Conbraco	40208T2Z	2	VUVU	8	2-Feb-1995	2-Feb-2004	(dd)	N	
RP	Conbraco	4020902	2 1/2	H	8	8-Apr-1991	8-Apr-2006	(tt),bb,ee,ll	N	
RP	Conbraco	4020903	2 1/2	H	8	8-Apr-1991	8-Apr-2006	(uu),cc,mm	N	
RP	Conbraco	4020905	2 1/2	H	8	8-Dec-1998	8-Dec-2004	(mmm)	N	
RP	Conbraco	4020A02	4	H	8	8-Apr-1991	8-Apr-2006	(tt),bb,ee,ll	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Conbraco	4020A03	4	H	8	8-Apr-1991	8-Apr-2006	(uu),cc,mm	N	
RP	Conbraco	4020A05	4	H	8	8-Dec-1998	8-Dec-2004	(mmm)	N	
RP	Conbraco	4020C02	6	H	8	8-Apr-1991	8-Apr-2006	(tt),bb,ee,ll	N	
RP	Conbraco	4020C03	6	H	8	8-Apr-1991	8-Apr-2006	(uu),cc,mm	N	
RP	Conbraco	4020C05	6	H	8	8-Dec-1998	8-Dec-2004	(mmm)	N	
RP	Conbraco	4020E02	8	H	8	22-Oct-1991	22-Oct-2006	(tt),bb,ee,ll	N	
RP	Conbraco	4020E03	8	H	8	22-Oct-1992	22-Oct-2004	(uu),cc,mm	N	
RP	Conbraco	4020G02	10	H	8	13-Apr-1993	13-Apr-2005	(tt),bb,ee,ll	N	
RP	Conbraco	4020G03	10	H	8	13-Apr-1993	13-Apr-2005	(uu),cc,mm	N	
RP	Febco	825	2 1/2	H	5	17-Mar-1975	17-Mar-2005		Y	
RP	Febco	825	3	H	5	16-Jun-1975	16-Jun-2005		Y	
RP	Febco	825	4	H	5	12-Jun-1975	12-Jun-2005		Y	
RP	Febco	825	6	H	5	6-Jun-1975	6-Jun-2005		Y	
RP	Febco	825	8	H	5	11-Nov-1975	11-Nov-2005		Y	
RP	Febco	825	10	H	5	23-Mar-1979	23-Mar-2006		Y	
RP	Febco	825D	2 1/2	H	7	13-Sep-1987	13-Sep-2005		Y	
RP	Febco	825D	3	H	7	13-Sep-1987	13-Sep-2005		Y	
RP	Febco	825D	4	H	7	13-Sep-1987	13-Sep-2005		Y	
RP	Febco	825D	6	H	7	13-Sep-1987	13-Sep-2005		Y	
RP	Febco	825D	8	H	7	13-Sep-1987	13-Sep-2005		Y	
RP	Febco	825D	10	H	7	13-Sep-1987	13-Sep-2005		Y	
RP	Febco	825Y	3/4	H	6	19-Mar-1982	19-Mar-2006	(ii),fff,jjj,ooo	N	
RP	Febco	825Y	1	H	6	19-Mar-1982	19-Mar-2006	(ii),fff,jjj,ooo	N	
RP	Febco	825Y	1 1/4	H	6	3-Jun-1982	3-Jun-2006	(ii),fff,jjj,ooo	N	
RP	Febco	825Y	1 1/2	H	6	6-Aug-1982	6-Aug-2006	(ii),fff,jjj,ooo	N	
RP	Febco	825Y	2	H	6	6-Aug-1982	6-Aug-2006	(ii),fff,ooo	N	
RP	Febco	825YA	3/4	H	8	5-Mar-1990	5-Mar-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	3/4	HVD	8	5-Mar-1990	5-Mar-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	3/4	VUH	8	5-Mar-1990	5-Mar-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	3/4	VUVD	8	5-Mar-1990	5-Mar-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	1	H	8	5-Mar-1990	5-Mar-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	1	HVD	8	5-Mar-1990	5-Mar-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	1	VUH	8	5-Mar-1990	5-Mar-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	1	VUVD	8	5-Mar-1990	5-Mar-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	1 1/2	H	8	8-May-1989	8-May-2004	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	1 1/2	HVD	8	8-May-1989	8-May-2004	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	1 1/2	VUH	8	8-May-1989	8-May-2004	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	1 1/2	VUVD	8	8-May-1989	8-May-2004	(ii),fff,jjj,ooo	N	
RP	Febco	825YA	2	H	8	8-May-1989	8-May-2004	(ii),fff,ooo	N	
RP	Febco	825YA	2	HVD	8	8-May-1989	8-May-2004	(ii),fff,ooo	N	
RP	Febco	825YA	2	VUH	8	8-May-1989	8-May-2004	(ii),fff,ooo	N	
RP	Febco	825YA	2	VUVD	8	8-May-1989	8-May-2004	(ii),fff,ooo	N	
RP	Febco	825YAR	3/4	H	8	22-Jan-1993	22-Jan-2005	(ii),fff,jjj,ooo	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Febco	825YAR	3/4	HVD	8	22-Jan-1993	22-Jan-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	3/4	VUH	8	22-Jan-1993	22-Jan-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	3/4	VUVD	8	22-Jan-1993	22-Jan-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	1	H	8	21-Jan-1993	21-Jan-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	1	HVD	8	21-Jan-1993	21-Jan-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	1	VUH	8	21-Jan-1993	21-Jan-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	1	VUVD	8	21-Jan-1993	21-Jan-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	1 1/2	H	8	19-Aug-1993	19-Aug-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	1 1/2	HVD	8	19-Aug-1993	19-Aug-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	1 1/2	VUH	8	19-Aug-1993	19-Aug-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	1 1/2	VUVD	8	19-Aug-1993	19-Aug-2005	(ii),fff,jjj,ooo	N	
RP	Febco	825YAR	2	H	8	19-Aug-1993	19-Aug-2005	(ii),fff,ooo	N	
RP	Febco	825YAR	2	HVD	8	19-Aug-1993	19-Aug-2005	(ii),fff,ooo	N	
RP	Febco	825YAR	2	VUH	8	19-Aug-1993	19-Aug-2005	(ii),fff,ooo	N	
RP	Febco	825YAR	2	VUVD	8	19-Aug-1993	19-Aug-2005	(ii),fff,ooo	N	
RP	Febco	825YD	2 1/2	H	7	24-Feb-1989	24-Feb-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	825YD	3	H	7	24-Feb-1989	24-Feb-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	825YD	4	H	7	24-Feb-1989	24-Feb-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	825YD	6	H	7	24-Feb-1989	24-Feb-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	825YD	8	H	7	24-Feb-1989	24-Feb-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	825YD	10	H	7	24-Feb-1989	24-Feb-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	825YR	3/4	H	8	22-Jan-1993	22-Jan-2005	(ii),fff,jjj	N	
RP	Febco	825YR	1	H	8	22-Jan-1993	22-Jan-2005	(ii),fff,jjj	N	
RP	Febco	825YR	1 1/2	H	8	23-Jul-1993	23-Jul-2005	(ii),fff,jjj	N	
RP	Febco	825YR	2	H	8	23-Jul-1993	23-Jul-2005	(ii),fff	N	
RP	Febco	835B	3/4	H	5	6-Mar-1979	6-Mar-2006		Y	
RP	Febco	835B	1	H	5	6-Mar-1979	6-Mar-2006		Y	
RP	Febco	835B	1 1/2	H	5	6-Mar-1979	6-Mar-2006		Y	
RP	Febco	835B	2	H	5	6-Mar-1979	6-Mar-2006		Y	
RP	Febco	860	1/2	H	9	9-Apr-1998	9-Apr-2004	(fff),ooo	N	
RP	Febco	860	3/4	H	9	21-Nov-1997	21-Nov-2003	(fff),jjj,ooo	N	
RP	Febco	860	1	H	9	21-Nov-1997	21-Nov-2003	(fff),jjj,ooo	N	
RP	Febco	860	1 1/4	H	9	4-Jun-1998	4-Jun-2004	(fff),jjj,ooo	N	
RP	Febco	860	1 1/2	H	9	9-Apr-1998	9-Apr-2004	(fff),jjj,ooo	N	
RP	Febco	860	2	H	9	9-Apr-1998	9-Apr-2004	(fff),ooo	N	
RP	Febco	860	2 1/2	H	8	19-Apr-1996	19-Apr-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
RP	Febco	860	3	H	8	19-Apr-1996	19-Apr-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,cccc,ffff,gggg	N	
RP	Febco	860	4	H	8	31-May-1995	31-May-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	860	6	H	8	7-Aug-1995	7-Aug-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	860	8	H	8	4-Oct-1995	4-Oct-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	860U	1/2	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
RP	Febco	860U	3/4	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
RP	Febco	860U	1	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	

T Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Febco	860U	1 1/4	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
RP	Febco	860U	1 1/2	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
RP	Febco	860U	2	H	9	12-Oct-1998	12-Oct-2004	(kkk)	N	
RP	Febco	867	2 1/2	H	8	1-Aug-2006		(oo), gg, hh,ll, mm, pp, tt, uu, yy, fff	N	
RP	Febco	867	3	H	8	1-Aug-2006		(oo), gg, hh,ll, mm, pp, tt, uu, yy, eee, fff	N	
RP	Febco	880	2 1/2	VUVD	8	24-May-1995	24-May-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	880	3	VUVD	8	24-May-1995	24-May-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	880	4	VUVD	8	10-Mar-1995	10-Mar-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	880	6	VUVD	8	19-May-1995	19-May-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	880	8	VUVD	8	19-May-1995	19-May-2004	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	880	10	VUVD	8	4-Oct-1996	4-Oct-2005	(ee),ff,ll,mm,oo,pp,tt,uu,zzz,ffff,gggg	N	
RP	Febco	880V	2 1/2	VUVD	8	30-Jun-1995	30-Jun-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	2 1/2	VUVU	8	30-Jun-1995	30-Jun-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	3	VUVD	8	30-Jun-1995	30-Jun-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	3	VUVU	8	30-Jun-1995	30-Jun-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	4	VUVD	8	8-Aug-1995	8-Aug-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	4	VUVU	8	8-Aug-1995	8-Aug-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	6	VUVD	8	5-Jul-1995	5-Jul-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	6	VUVU	8	5-Jul-1995	5-Jul-2004	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	8	VUVD	8	18-Dec-1996	18-Dec-2005	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	8	VUVU	8	18-Dec-1996	18-Dec-2005	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	10	VUVD	8	17-Jun-1997	17-Jun-2006	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Febco	880V	10	VUVU	8	17-Jun-1997	17-Jun-2006	(ee),ff,ll,mm,oo,pp,tt,uu,nnn,zzz,cccc,ffff,gggg	N	
RP	Flomatic	RPZ	3/4	H	8	7-Jun-1994	17-Jun-2006	(ii)	N	
RP	Flomatic	RPZ	1	H	8	7-Jun-1994	17-Jun-2006	(ii)	N	
RP	Flomatic	RPZ	1 1/2	H	8	10-May-1995	10-May-2004	(ii)	N	
RP	Flomatic	RPZ	2	H	8	10-May-1995	10-May-2004	(ii)	N	
RP	Flomatic	RPZ	2 1/2	H	8	14-Feb-1997	14-Feb-2006	(gg),hh,jj,kk,ll,mm,yy,zz,ccc,ddd	N	
RP	Flomatic	RPZ	3	H	8	14-Feb-1997	14-Feb-2006	(gg),hh,jj,kk,ll,mm,yy,zz,ccc,ddd	N	
RP	Flomatic	RPZ	4	H	9	28-Jan-1999	28-Jan-2004	(gg),hh,jj,kk,ll,mm,yy,zz,ccc,ddd	N	
RP	Flomatic	RPZ	6	H	9	31-Jan-2002	31-Jan-2005	(gg),hh,jj,kk,ll,mm,yy,zz,ccc,ddd	N	
RP	Flomatic	RPZ	8	H	9	5-Feb-2005		(gg), hh, jj, kk, ll, mm, yy, zz, ccc, ddd	N	
RP	Flomatic	RPZE	3/4	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
RP	Flomatic	RPZE	1	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
RP	Flomatic	RPZE	1 1/2	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
RP	Flomatic	RPZE	2	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
RP	Flomatic	RPZII	1/2	H	8	15-Aug-1997	15-Aug-2006	(ii)	N	
RP	Flomatic	RPZII	3/4	H	8	15-Aug-1997	15-Aug-2006	(ii)	N	
RP	Flomatic	RPZIIIE	1/2	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
RP	Flomatic	RPZIIIE	3/4	H	8	7-Jun-2001	7-Jun-2004	(ii)	N	
RP	Neptune									
RP	RainBird									
RP	Watts	009	2 1/2	H	8	31-Aug-1990	31-Aug-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
RP	Watts	009	3	H	8	31-Aug-1990	31-Aug-2005	(oo,gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
RP	Watts	009	4	H	8	17-Feb-1995	17-Feb-2004	(oo,gg,hh,ll,mm,pp,tt,uu,yy	Y	
RP	Watts	009	6	H	8	17-Feb-1995	17-Feb-2004	(oo,gg,hh,ll,mm,pp,tt,uu,yy	Y	
RP	Watts	009M1PCQT	1 1/4	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009M1PCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009M1PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009M1QT	1 1/4	H	8	30-Jun-1992	30-Jun-2004	(vv),xx	Y	
RP	Watts	009M1QT	1 1/2	H	8	30-Jun-1992	30-Jun-2004	(vv),xx	Y	
RP	Watts	009M1QT	2	H	8	19-Dec-1991	19-Dec-2003	(vv),xx	Y	
RP	Watts	009M2PCQT	3/4	H	8	7-Oct-2002	7-Oct-2005	(vv),xx	N	
RP	Watts	009M2PCQT	1	H	9	15-Jan-1999	15-Jan-2005	(vv),xx	N	
RP	Watts	009M2PCQT	1 1/4	H	8	12-Sep-1994	12-Sep-2006	(vv),xx	N	
RP	Watts	009M2PCQT	1 1/2	H	8	12-Sep-1994	12-Sep-2006	(vv),xx	N	
RP	Watts	009M2PCQT	2	H	9	26-Aug-1997	26-Aug-2006	(vv),xx	N	
RP	Watts	009M2QT	3/4	H	8	31-Oct-1992	31-Oct-2004	(vv),xx	N	
RP	Watts	009M2QT	1	H	9	18-May-1998	18-May-2004	(vv),xx	N	
RP	Watts	009M2QT	1 1/4	H	8	24-Aug-1993	24-Aug-2005	(vv),xx	N	
RP	Watts	009M2QT	1 1/2	H	8	24-Aug-1993	24-Aug-2005	(vv),xx	N	
RP	Watts	009M2QT	2	H	9	10-Sep-1996	10-Sep-2005	(vv),xx	N	
RP	Watts	009M3QT	3/4	H	9	18-Oct-1999	18-Oct-2005	(vv),xx	N	
RP	Watts	009PCQT	1/2	H	8	17-Feb-1995	17-Feb-2004	(vv),xx	N	
RP	Watts	009PCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(vv),xx	N	
RP	Watts	009PCQT	1	H	8	10-Dec-1993	10-Dec-2005	(vv),xx	Y	
RP	Watts	009PCQT	1 1/4	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009PCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009QT	1/4	H	8	7-Aug-1995	7-Aug-2004	(vv),xx	N	
RP	Watts	009QT	3/8	H	8	7-Aug-1995	7-Aug-2004	(vv),xx	N	
RP	Watts	009QT	1/2	H	9	10-Sep-1996	10-Sep-2005	(vv),xx	N	
RP	Watts	009QT	3/4	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	N	
RP	Watts	009QT	1	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	Y	
RP	Watts	009QT	1 1/4	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	009QT	1 1/2	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	009QT	2	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	009SSM1PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009SSM1QT	2	H	8	19-Dec-1991	19-Dec-2003	(vv),xx	Y	
RP	Watts	009SSPCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(vv),xx	Y	
RP	Watts	009SSPCQT	1	H	8	10-Dec-1993	10-Dec-2005	(vv),xx	Y	
RP	Watts	009SSPCQT	1 1/4	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009SSPCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009SSPCQT	2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	009SSQT	3/4	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	Y	
RP	Watts	009SSQT	1	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	Y	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Watts	009SSQT	1 1/4	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	009SSQT	1 1/2	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	009SSQT	2	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	909	2 1/2	H	7	12-Jun-1986	12-Jun-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
RP	Watts	909	3	H	7	12-Jun-1986	12-Jun-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
RP	Watts	909	4	H	6	15-Jan-1982	15-Jan-2006	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
RP	Watts	909	6	H	6	6-Jul-1981	6-Jul-2005	(oo),gg,hh,ll,mm,pp,tt,uu,yy,eee,ffff,gggg	N	
RP	Watts	909	8	H	6	6-Jul-1981	6-Jul-2005		Y	
RP	Watts	909	10	H	6	6-Jul-1981	6-Jul-2005		Y	
RP	Watts	909BB	2 1/2	H	6	4-Feb-1983	4-Feb-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
RP	Watts	909BB	3	H	6	4-Feb-1983	4-Feb-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,fff,gggg	N	
RP	Watts	909HWM1QT	1 1/4	H	5	7-Feb-1980	7-Feb-2004	(vv),xx	N	
RP	Watts	909HWM1QT	1 1/2	H	5	7-Feb-1980	7-Feb-2004	(vv),xx	N	
RP	Watts	909HWM1QT	2	H	5	7-Feb-1980	7-Feb-2004	(vv),xx	N	
RP	Watts	909HWQT	3/4	H	5	29-Sep-1979	29-Sep-2006	(vv),xx	N	
RP	Watts	909HWQT	1	H	5	29-Sep-1979	29-Sep-2006	(vv),xx	N	
RP	Watts	909M1	8	H	8	1-May-1989	1-May-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
RP	Watts	909M1	10	H	8	1-May-1989	1-May-2004	(oo),gg,hh,ll,mm,pp,tt,uu,yy,ffff,gggg	N	
RP	Watts	909M1QT	1 1/4	H	6	15-Jan-1982	15-Jan-2006	(vv),xx,ffff,gggg	N	
RP	Watts	909M1QT	1 1/2	H	6	15-Jan-1982	15-Jan-2006	(vv),xx,ffff,gggg	N	
RP	Watts	909M1QT	2	H	6	15-Jan-1982	15-Jan-2006	(vv),xx,ffff,gggg	N	
RP	Watts	909M1QTFDA	8	H	8	15-Oct-1990	15-Oct-2005	(ww),ffff,gggg	N	
RP	Watts	909M1QTFDA	10	H	8	15-Oct-1990	15-Oct-2005	(ww),ffff,gggg	N	
RP	Watts	909PCHWM1QT	1 1/4	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	909PCHWM1QT	1 1/2	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	909PCHWM1QT	2	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	909PCHWQT	3/4	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	909PCHWQT	1	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	909PCM1QT	1 1/4	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	909PCM1QT	1 1/2	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	909PCM1QT	2	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	909PCQT	3/4	H	9	9-Oct-1998	9-Oct-2004	(vv),xx	N	
RP	Watts	909PCQT	3/4	VU	9	9-Oct-1998	9-Oct-2004	(vv),xx	N	
RP	Watts	909PCQT	1	H	9	9-Oct-1998	9-Oct-2004	(vv),xx	N	
RP	Watts	909PCQT	1	VU	9	9-Oct-1998	9-Oct-2004	(vv),xx	N	
RP	Watts	909QT	3/4	H	9	18-Jun-1998	18-Jun-2004	(vv),xx	N	
RP	Watts	909QT	3/4	VU	9	18-Jun-1998	18-Jun-2004	(vv),xx	N	
RP	Watts	909QT	1	H	9	18-Jun-1998	18-Jun-2004	(vv),xx	N	
RP	Watts	909QT	1	VU	9	18-Jun-1998	18-Jun-2004	(vv),xx	N	
RP	Watts	909QTFDA	2 1/2	H	8	15-Oct-1990	15-Oct-2005	(ww),ffff,gggg	N	
RP	Watts	909QTFDA	3	H	8	15-Oct-1990	15-Oct-2005	(ww),ffff,gggg	N	
RP	Watts	909QTFDA	4	H	8	15-Oct-1990	15-Oct-2005	(ww),ffff,gggg	N	
RP	Watts	909QTFDA	6	H	8	15-Oct-1990	15-Oct-2005	(ww),ffff,gggg	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Watts	919AQT	3/4	VUVD	9	14-Jun-2006		(vv), hhhh	N	
RP	Watts	919AQT	1	VUVD	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919AQT	1 1/4	VUVD	9	5-Sep-2006		(vv), hhhh	N	
RP	Watts	919AQT	1 1/2	VUVD	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919AQT	2	VUVD	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919QT	3/4	H	9	14-Jun-2006		(vv), hhhh	N	
RP	Watts	919QT	3/4	VD	9	30-Aug-2006		(vv), hhhh	N	
RP	Watts	919QT	1	H	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919QT	1	VD	9	30-Aug-2006		(vv), hhhh	N	
RP	Watts	919QT	1 1/4	H	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919QT	1 1/4	VD	9	30-Aug-2006		(vv), hhhh	N	
RP	Watts	919QT	1 1/2	H	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919QT	1 1/2	VD	9	30-Aug-2006		(vv), hhhh	N	
RP	Watts	919QT	2	H	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919QT	2	VD	9	30-Aug-2006		(vv), hhhh	N	
RP	Watts	919ZQT	3/4	VUVU	9	14-Jun-2006		(vv), hhhh	N	
RP	Watts	919ZQT	1	VUVU	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919ZQT	1 1/4	VUVU	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919ZQT	1 1/2	VUVU	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	919ZQT	2	VUVU	9	1-Jun-06		(vv), hhhh	N	
RP	Watts	957	2 1/2	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	957	3	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	957	4	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	957	6	H	9	20-Dec-2004		(ppp), qqq,aaaa, bbbb,ffff,gggg	N	
RP	Watts	957N	2 1/2	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	957N	3	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	957N	4	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	957Z	2 1/2	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	957Z	3	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	957Z	4	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	967	2 1/2	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	967	3	H	9	7-Oct-2002	7-Oct-2005	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	967	4	H	9	18-Jan-2005		(ppp), qqq, aaaa, bbbb,ffff,gggg	N	
RP	Watts	967N	2 1/2	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	967N	3	VUVD	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	967Z	2 1/2	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,yyy,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	967Z	3	VUVU	9	14-Apr-2003	14-Apr-2006	(ppp),qqq,zzz,aaaa,bbbb,dddd,eeee,ffff,gggg	N	
RP	Watts	990	4	H	8	1-Nov-1992	1-Nov-2004	(oo),gg,hh,pp,tt,uu,yy	Y	
RP	Watts	990	8	H	8	13-Jan-1993	13-Jan-2005	(oo),gg,hh,pp,tt,uu,yy	Y	
RP	Watts	990QTFDA	4	H	8	13-Jan-1993	13-Jan-2005	(ww)	Y	
RP	Watts	990QTFDA	8	H	8	13-Jan-1993	13-Jan-2005	(ww)	Y	
RP	Watts	992	4	H	8	1-Nov-1992	1-Nov-2004	(oo)	Y	
RP	Watts	992	10	H	8	13-Jan-1993	13-Jan-2005	(oo)	Y	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Watts	994	2 1/2	H	8	15-Apr-1994	15-Apr-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Watts	994	3	H	8	15-Apr-1994	15-Apr-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Watts	994	4	H	8	15-Apr-1994	15-Apr-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Watts	994	6	H	8	22-Sep-1997	22-Sep-2006	(tt),ee,ff,gg,hh,ll,mm,oo,pp,uu,ccc,ddd,ffff,gggg	N	
RP	Watts	995QT	1/2	H	9	13-Apr-2000	13-Apr-2006	(int)	N	
RP	Watts	995QT	3/4	H	9	13-Apr-2000	13-Apr-2006	(int)	N	
RP	Watts	995QT	1	H	9	14-Jan-1999	14-Jan-2005	(int)	N	
RP	Watts	995QT	1 1/4	H	9	28-Mar-2002	28-Mar-2005	(int)	N	
RP	Watts	995QT	1 1/2	H	9	28-Mar-2002	28-Mar-2005	(int)	N	
RP	Watts	FAE909HWQT	1 1/4	H	5	7-Feb-1980	7-Feb-2004	(vv),xx	N	
RP	Watts	FAE909HWQT	1 1/2	H	5	7-Feb-1980	7-Feb-2004	(vv),xx	N	
RP	Watts	FAE909HWQT	2	H	5	7-Feb-1980	7-Feb-2004	(vv),xx	N	
RP	Watts	FAE909QT	1 1/4	H	6	15-Jan-1982	15-Jan-2006	(vv),xx	N	
RP	Watts	FAE909QT	1 1/2	H	6	15-Jan-1982	15-Jan-2006	(vv),xx	N	
RP	Watts	FAE909QT	2	H	6	15-Jan-1982	15-Jan-2006	(vv),xx	N	
RP	Watts	LF919AQT	3/4	VUVD	9	14-Jun-2006		(vvv), hhhh	N	
RP	Watts	LF919AQT	1	VUVD	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919AQT	1 1/4	VUVD	9	5-Sep-2006		(vvv), hhhh	N	
RP	Watts	LF919AQT	1 1/2	VUVD	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919AQT	2	VUVD	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	3/4	H	9	14-Jun-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	3/4	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	1	H	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	1	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	1 1/4	H	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	1 1/4	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	1 1/2	H	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	1 1/2	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	2	H	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919QT	2	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Watts	LF919ZQT	3/4	VUVU	9	14-Jun-2006		(vvv), hhhh	N	
RP	Watts	LF919ZQT	1	VUVU	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919ZQT	1 1/4	VUVU	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919ZQT	1 1/2	VUVU	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LF919ZQT	2	VUVU	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LFU919AQT	3/4	VUVD	9	14-Jun-2006		(vvv), hhhh	N	
RP	Watts	LFU919AQT	1	VUVD	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LFU919AQT	1 1/4	VUVD	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LFU919AQT	1 1/2	VUVD	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LFU919AQT	2	VUVD	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LFU919QT	3/4	H	9	14-Jun-2006		(vvv), hhhh	N	
RP	Watts	LFU919QT	1	H	9	12-Apr-2006		(vvv), hhhh	N	
RP	Watts	LFU919QT	1	VD	9	30-Aug-2006		(vvv), hhhh	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Watts	LFU919QT	1 1/4	H	9	12-Apr-2006		(vv), hhhh	N	
RP	Watts	LFU919QT	1 1/4	VD	9	30-Aug-2006		(vv), hhhh	N	
RP	Watts	LFU919QT	1 1/2	H	9	12-Apr-2006		(vv), hhhh	N	
RP	Watts	LFU919QT	1 1/2	VD	9	30-Aug-2006		(vv), hhhh	N	
RP	Watts	LFU919QT	2	H	9	12-Apr-2006		(vv), hhhh	N	
RP	Watts	LFU919QT	2	VD	9	30-Aug-2006		(vv), hhhh	N	
RP	Watts	SS009M3QT	1/4	H	9	19-Dec-2001	19-Dec-2004	(hhh)	N	
RP	Watts	SS009M3QT	3/8	H	9	19-Dec-2001	19-Dec-2004	(hhh)	N	
RP	Watts	SS009M3QT	1/2	H	9	19-Dec-2001	19-Dec-2004	(hhh)	N	
RP	Watts	SS009M3QT	3/4	H	9	31-Jul-2001	31-Jul-2004	(hhh)	N	
RP	Watts	SS009QT	1	H	9	18-May-1998	18-May-2004	(hhh)	N	
RP	Watts	U009APCQT	3/4	VDVD	8	10-Dec-1993	10-Dec-2005	(vv),xx	N	
RP	Watts	U009APCQT	3/4	VDVU	8	10-Dec-1993	10-Dec-2005	(v),xx	N	
RP	Watts	U009APCQT	3/4	VUVD	8	10-Dec-1993	10-Dec-2005	(vv),xx	N	
RP	Watts	U009APCQT	3/4	VUVU	8	10-Dec-1993	10-Dec-2005	(vv),xx	N	
RP	Watts	U009APCQT	1	VDVD	8	10-Dec-1993	10-Dec-2005	(v),xx	Y	
RP	Watts	U009APCQT	1	VDVU	8	10-Dec-1993	10-Dec-2005	(v),xx	Y	
RP	Watts	U009APCQT	1	VUVD	8	10-Dec-1993	10-Dec-2005	(vv),xx	Y	
RP	Watts	U009APCQT	1	VUVU	8	10-Dec-1993	10-Dec-2005	(v),xx	Y	
RP	Watts	U009AQT	3/4	VDVD	8	12-Jun-1992	12-Jun-2004	(vv),xx	N	
RP	Watts	U009AQT	3/4	VDVU	8	12-Jun-1992	12-Jun-2004	(v),xx	N	
RP	Watts	U009AQT	3/4	VUVD	8	12-Jun-1992	12-Jun-2004	(vv),xx	N	
RP	Watts	U009AQT	3/4	VUVU	8	12-Jun-1992	12-Jun-2004	(vv),xx	N	
RP	Watts	U009AQT	1	VDVD	8	12-Jun-1992	12-Jun-2004	(v),xx	Y	
RP	Watts	U009AQT	1	VDVU	8	12-Jun-1992	12-Jun-2004	(v),xx	Y	
RP	Watts	U009AQT	1	VUVD	8	12-Jun-1992	12-Jun-2004	(vv),xx	Y	
RP	Watts	U009AQT	1	VUVU	8	12-Jun-1992	12-Jun-2004	(v),xx	Y	
RP	Watts	U009M1APCQT	1 1/2	VDVD	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009M1APCQT	1 1/2	VDVU	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009M1APCQT	1 1/2	VUVD	8	27-Sep-1994	27-Sep-2006	(v),xx	Y	
RP	Watts	U009M1APCQT	1 1/2	VUVU	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009M1APCQT	2	VDVD	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009M1APCQT	2	VDVU	8	27-Sep-1994	27-Sep-2006	(v),xx	Y	
RP	Watts	U009M1APCQT	2	VUVD	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009M1APCQT	2	VUVU	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009M1AQT	1 1/2	VDVD	8	16-Dec-1992	16-Dec-2004	(v),xx	Y	
RP	Watts	U009M1AQT	1 1/2	VDVU	8	16-Dec-1992	16-Dec-2004	(v),xx	Y	
RP	Watts	U009M1AQT	1 1/2	VUVD	8	16-Dec-1992	16-Dec-2004	(vv),xx	Y	
RP	Watts	U009M1AQT	1 1/2	VUVU	8	16-Dec-1992	16-Dec-2004	(v),xx	Y	
RP	Watts	U009M1AQT	2	VDVD	8	9-Nov-1992	9-Nov-2004	(vv),xx	Y	
RP	Watts	U009M1AQT	2	VDVU	8	9-Nov-1992	9-Nov-2004	(v),xx	Y	
RP	Watts	U009M1AQT	2	VUVD	8	9-Nov-1992	9-Nov-2004	(v),xx	Y	
RP	Watts	U009M1AQT	2	VUVU	8	9-Nov-1992	9-Nov-2004	(vv),xx	Y	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
RP	Watts	U009M1PCQT	1 1/4	H	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
RP	Watts	U009M1PCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
RP	Watts	U009M1PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	N	
RP	Watts	U009M1QT	1 1/4	H	8	30-Jun-1992	30-Jun-2004	(w),xx	N	
RP	Watts	U009M1QT	1 1/2	H	8	30-Jun-1992	30-Jun-2004	(w),xx	Y	
RP	Watts	U009M1QT	2	H	8	30-Jun-1992	30-Jun-2004	(w),xx	Y	
RP	Watts	U009M2APCQT	1	VDVD	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2APCQT	1	VDVU	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2APCQT	1	VUVD	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2APCQT	1	VUVU	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2APCQT	1 1/2	VDVD	8	12-Sep-1994	12-Sep-2006	(w),xx	N	
RP	Watts	U009M2APCQT	1 1/2	VDVU	8	12-Sep-1994	12-Sep-2006	(w),xx	N	
RP	Watts	U009M2APCQT	1 1/2	VUVD	8	12-Sep-1994	12-Sep-2006	(w),xx	N	
RP	Watts	U009M2APCQT	1 1/2	VUVU	8	12-Sep-1994	12-Sep-2006	(w),xx	N	
RP	Watts	U009M2APCQT	2	VDVD	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2APCQT	2	VDVU	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2APCQT	2	VUVD	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2APCQT	2	VUVU	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2AQT	1	VDVD	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2AQT	1	VDVU	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2AQT	1	VUVD	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2AQT	1	VUVU	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2AQT	1 1/2	VDVD	8	24-Aug-1993	24-Aug-2005	(w),xx	N	
RP	Watts	U009M2AQT	1 1/2	VDVU	8	24-Aug-1993	24-Aug-2005	(w),xx	N	
RP	Watts	U009M2AQT	1 1/2	VUVD	8	24-Aug-1993	24-Aug-2005	(w),xx	N	
RP	Watts	U009M2AQT	1 1/2	VUVU	8	24-Aug-1993	24-Aug-2005	(w),xx	N	
RP	Watts	U009M2AQT	2	VDVD	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2AQT	2	VDVU	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2AQT	2	VUVD	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2AQT	2	VUVU	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2PCQT	1	H	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2PCQT	1 1/2	H	8	12-Sep-1994	12-Sep-2006	(w),xx	N	
RP	Watts	U009M2PCQT	2	H	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009M2QT	3/4	H	8	16-Nov-1992	16-Nov-2004	(w),xx	N	
RP	Watts	U009M2QT	1	H	9	15-Jan-1999	15-Jan-2005	(w),xx	N	
RP	Watts	U009M2QT	1 1/2	H	8	24-Aug-1993	24-Aug-2005	(w),xx	N	
RP	Watts	U009M2QT	2	H	9	26-Aug-1997	26-Aug-2006	(w),xx	N	
RP	Watts	U009PCQT	1/2	H	8	2-Feb-1995	2-Feb-2004	(w),xx	N	
RP	Watts	U009PCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(w),xx	N	
RP	Watts	U009PCQT	1	H	8	10-Dec-1993	10-Dec-2005	(w),xx	Y	
RP	Watts	U009PCQT	1 1/4	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
RP	Watts	U009PCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	
RP	Watts	U009PCQT	2	H	8	27-Sep-1994	27-Sep-2006	(w),xx	Y	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
RP	Watts	U009QT	1/2	H	8	2-Feb-1995	2-Feb-2004	(vv),xx	N	
RP	Watts	U009QT	3/4	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	Y	
RP	Watts	U009QT	1	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	Y	
RP	Watts	U009QT	1 1/4	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	U009QT	1 1/2	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	U009QT	2	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	U009SSPCQT	3/4	H	8	10-Dec-1993	10-Dec-2005	(vv),xx	Y	
RP	Watts	U009SSPCQT	1	H	8	10-Dec-1993	10-Dec-2005	(vv),xx	Y	
RP	Watts	U009SSPCQT	1 1/4	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009SSPCQT	1 1/2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009SSPCQT	2	H	8	27-Sep-1994	27-Sep-2006	(vv),xx	Y	
RP	Watts	U009SSQT	3/4	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	Y	
RP	Watts	U009SSQT	1	H	7	11-Jan-1988	11-Jan-2006	(vv),xx	Y	
RP	Watts	U009SSQT	1 1/4	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	U009SSQT	1 1/2	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	U009SSQT	2	H	7	9-Aug-1988	9-Aug-2006	(vv),xx	Y	
RP	Watts	U909HWQT	3/4	H	5	29-Sep-1979	29-Sep-2006	(vv),xx	N	
RP	Watts	U909HWQT	1	H	5	29-Sep-1979	29-Sep-2006	(vv),xx	N	
RP	Watts	U909QT	3/4	H	9	9-Oct-1998	9-Oct-2004	(vv),xx	N	
RP	Watts	U909QT	3/4	VU	9	9-Oct-1998	9-Oct-2004	(vv),xx	N	
RP	Watts	U909QT	1	H	9	9-Oct-1998	9-Oct-2004	(vv),xx	N	
RP	Watts	U909QT	1	VU	9	9-Oct-1998	9-Oct-2004	(vv),xx	N	
RP	Watts	U919AQT	3/4	VUVD	9	14-Jun-2006		(vvv), hhhh	N	
RP	Watts	U919AQT	1	VUVD	9	1-Jun-06		(vvv), hhhh	N	
RP	Watts	U919AQT	1 1/4	VUVD	9	1-Jun-06		(vvv), hhhh	N	
RP	Watts	U919AQT	1 1/2	VUVD	9	1-Jun-06		(vvv), hhhh	N	
RP	Watts	U919AQT	2	VUVD	9	1-Jun-06		(vvv), hhhh	N	
RP	Watts	U919QT	1	H	9	1-Jun-06		(vvv), hhhh	N	
RP	Watts	U919QT	1	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Watts	U919QT	1 1/4	H	9	1-Jun-06		(vvv), hhhh	N	
RP	Watts	U919QT	1 1/4	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Watts	U919QT	1 1/2	H	9	1-Jun-06		(vvv), hhhh	N	
RP	Watts	U919QT	1 1/2	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Watts	U919QT	2	H	9	1-Jun-06		(vvv), hhhh	N	
RP	Watts	U919QT	2	VD	9	30-Aug-2006		(vvv), hhhh	N	
RP	Wilkins	375	2 1/2	H	9	28-Sep-2001	28-Sep-2004	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	375	3	H	9	28-Sep-2001	28-Sep-2004	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	375	4	H	9	27-Mar-2000	27-Mar-2006	(qq),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
RP	Wilkins	375	6	H	9	27-Jul-2000	27-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
RP	Wilkins	375	8	H	9	11-Nov-2002	11-Nov-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
RP	Wilkins	375	10	H	9	22-Nov-2004		(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
RP	Wilkins	375A	4	H	9	2-Jun-2004		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	375A	6	H	9	25-Nov-2003		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RP	Wilkins	375A	8	H	9	15-Jun-2004		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	375MS	2 1/2	H	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	375MS	3	H	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	375MS	4	H	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
RP	Wilkins	375MS	6	H	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
RP	Wilkins	375MS	8	H	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
RP	Wilkins	375MS	10	H	9	29-Mar-2005		(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,vvv,www,zzz,ddd	N	
RP	Wilkins	475	2 1/2	VUVD	9	24-Jan-2002	24-Jan-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	475	3	VUVD	9	24-Jan-2002	24-Jan-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	475	4	VUVD	9	27-Jul-2000	27-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475	6	VUVD	9	27-Jul-2000	27-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475	8	VUVD	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475	10	VUVD	9	22-Nov-2004		(ppp),qqq,sss,ttt,www,zzz,dddd,eeee	N	
RP	Wilkins	475MS	2 1/2	VUVD	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	475MS	3	VUVD	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	475MS	4	VUVD	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475MS	6	VUVD	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475MS	8	VUVD	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475MS	10	H	9	29-Mar-2005		(ppp),qqq,sss,ttt,www,zzz,dddd,eeee	N	
RP	Wilkins	475V	2 1/2	VUVU	9	24-Jan-2002	24-Jan-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	475V	3	VUVU	9	24-Jan-2002	24-Jan-2005	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	475V	4	VUVU	9	9-Sep-2000	9-Sep-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475V	6	VUVU	9	31-May-2001	31-May-2004	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475V	8	VUVU	9	8-Jun-2004		(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475V	10	VUVU	9	22-Nov-2004		(ppp),qqq,sss,ttt,www,zzz,dddd,eeee	N	
RP	Wilkins	475VMS	2 1/2	VUVU	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	475VMS	3	VUVU	9	3-Jul-2003	3-Jul-2006	(gg),ee,ff,hh,ll,mm,tt,uu,yy,zz,ppp,qqq,zzz,dddd	N	
RP	Wilkins	475VMS	4	VUVU	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475VMS	6	VUVU	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475VMS	8	VUVU	9	3-Jul-2003	3-Jul-2006	(ppp),qqq,sss,ttt,www,yyy,zzz,dddd,eeee	N	
RP	Wilkins	475VMS	10	H	9	29-Mar-2005		(ppp),qqq,sss,ttt,www,zzz,dddd,eeee	N	
RP	Wilkins	575	3/4	H	5	28-Apr-1976	28-Apr-2006		Y	
RP	Wilkins	575	1	H	5	28-Apr-1976	28-Apr-2006		Y	
RP	Wilkins	575	2 1/2	H	7	25-Sep-1986	25-Sep-2004	(gg),ee,tt,yy	Y	
RP	Wilkins	575	3	H	5	20-Aug-1979	20-Aug-2006	(gg),ee,tt,yy	Y	
RP	Wilkins	575	4	H	5	8-Jun-1980	8-Jun-2004	(gg),ee,tt,yy	Y	
RP	Wilkins	575	6	H	6	6-Jul-1981	6-Jul-2005	(gg),ee,tt,yy	Y	
RP	Wilkins	575 (MOD-III)	1 1/4	H	5	11-Oct-1976	11-Oct-2006	(ii)	Y	
RP	Wilkins	575 (MOD-III)	1 1/2	H	5	11-Oct-1976	11-Oct-2006	(ii)	Y	
RP	Wilkins	575 (MOD-III)	2	H	5	11-Oct-1976	11-Oct-2006	(ii)	Y	
RP	Wilkins	575A	3/4	H	7	17-Apr-1987	17-Apr-2005	(ii)	Y	
RP	Wilkins	575A	1	H	7	17-Apr-1987	17-Apr-2005	(ii)	Y	
RP	Wilkins	575M10	10	H	6	1-Jun-1983	1-Jun-2004	(gg),ee,tt,yy	Y	

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
RP	Wilkins	575M8	8	H	6	11-Apr-1983	11-Apr-2004	(gg),ee,tt,yy	Y	
RP	Wilkins	975	3/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975	1	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975	1 1/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975	1 1/2	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975	2	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975	2 1/2	H	8	26-Nov-1991	26-Nov-2003	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975	3	H	8	8-Nov-1991	8-Nov-2003	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975	4	H	8	8-Nov-1991	8-Nov-2003	(gg),ee,ff,hh,tt,uu,yy,zz,ppp	N	
RP	Wilkins	975	6	H	8	8-Nov-1991	8-Nov-2003	(gg),ee,ff,hh,tt,uu,yy,zz,ppp	N	
RP	Wilkins	975	8	H	8	6-Feb-1995	6-Feb-2004	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975	10	H	8	6-Feb-1995	6-Feb-2004	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975A	3/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975A	1	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975A	1 1/4	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975A	1 1/2	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975A	2	H	8	18-Jul-1991	18-Jul-2006	(ii)	N	
RP	Wilkins	975BMS	2 1/2	H	8	17-Jun-1997	17-Jun-2006	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975BMS	3	H	8	17-Jun-1997	17-Jun-2006	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975BMS	4	H	8	17-Jun-1997	17-Jun-2006	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975BMS	6	H	8	17-Jun-1997	17-Jun-2006	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975BMS	8	H	8	17-Jun-1997	17-Jun-2006	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975BMS	10	H	8	17-Jun-1997	17-Jun-2006	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975MS	2 1/2	H	8	5-May-1995	5-May-2004	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975MS	3	H	8	5-May-1995	5-May-2004	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975MS	4	H	8	5-May-1995	5-May-2004	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975MS	6	H	8	5-May-1995	5-May-2004	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975MS	8	H	8	5-Dec-1996	5-Dec-2005	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975MS	10	H	8	5-Dec-1996	5-Dec-2005	(gg),ee,ff,hh,tt,uu,yy,zz	N	
RP	Wilkins	975XL	1/4	H	8	12-Jul-1994	12-Jul-2006	(ii)	N	
RP	Wilkins	975XL	3/8	H	8	12-Jul-1994	12-Jul-2006	(ii)	N	
RP	Wilkins	975XL	1/2	H	8	12-Jul-1994	12-Jul-2006	(ii)	N	
RP	Wilkins	975XL	3/4	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo	N	
RP	Wilkins	975XL	1	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo	N	
RP	Wilkins	975XL	1 1/4	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo,ggg	N	
RP	Wilkins	975XL	1 1/2	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo	N	
RP	Wilkins	975XL	2	H	8	2-Nov-1992	2-Nov-2004	(ii),ooo	N	
RP	Wilkins	975XLBMS	3/4	H	8	9-May-1997	9-May-2006	(ii),ooo	N	
RP	Wilkins	975XLBMS	1	H	8	9-May-1997	9-May-2006	(ii),ooo	N	
RP	Wilkins	975XLBMS	1 1/4	H	8	9-May-1997	9-May-2006	(ii),ooo	N	
RP	Wilkins	975XLBMS	1 1/2	H	8	9-May-1997	9-May-2006	(ii),ooo	N	
RP	Wilkins	975XLBMS	2	H	8	9-May-1997	9-May-2006	(ii),ooo	N	
RP	Wilkins	975XLD	3/4	H	9	8-Oct-2002	8-Oct-2005	(ii),ooo	N	

T type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
RP	Wilkins	975XLMS	3/4	H	8	30-Aug-1994	30-Aug-2006	(ii),ooo	N	
RP	Wilkins	975XLMS	1	H	8	30-Aug-1994	30-Aug-2006	(ii),ooo	N	
RP	Wilkins	975XLMS	1 1/4	H	8	30-Aug-1994	30-Aug-2006	(ii),ooo	N	
RP	Wilkins	975XLMS	1 1/2	H	8	30-Aug-1994	30-Aug-2006	(ii),ooo	N	
RP	Wilkins	975XLMS	2	H	8	30-Aug-1994	30-Aug-2006	(ii),ooo	N	
RP	Wilkins	975XLSE	3/4	VUVD	9	16-Oct-2000	16-Oct-2006	(ii),ooo	N	
RP	Wilkins	975XLSE	3/4	VUVU	9	16-Oct-2000	16-Oct-2006	(ii),ooo	N	
RP	Wilkins	975XLSE	1	VUVD	9	16-Oct-2000	16-Oct-2006	(ii),ooo	N	
RP	Wilkins	975XLSE	1	VUVU	9	16-Oct-2000	16-Oct-2006	(ii),ooo	N	
RP	Wilkins	975XLSE	1 1/4	VUVD	9	4-Nov-1999	4-Nov-2005	(ii),ooo	N	
RP	Wilkins	975XLSE	1 1/4	VUVU	9	4-Nov-1999	4-Nov-2005	(ii),ooo	N	
RP	Wilkins	975XLSE	1 1/2	VUVD	9	4-Nov-1999	4-Nov-2005	(ii),ooo	N	
RP	Wilkins	975XLSE	1 1/2	VUVU	9	4-Nov-1999	4-Nov-2005	(ii),ooo	N	
RP	Wilkins	975XLSE	2	VUVD	9	4-Nov-1999	4-Nov-2005	(ii),ooo	N	
RP	Wilkins	975XLSE	2	VUVU	9	4-Nov-1999	4-Nov-2005	(ii),ooo	N	
RP	Wilkins	975XLSEU	3/4	VUVD	9	16-Oct-2000	16-Oct-2006	(ggg)	N	
RP	Wilkins	975XLSEU	3/4	VUVU	9	16-Oct-2000	16-Oct-2006	(ggg)	N	
RP	Wilkins	975XLSEU	1	VUVD	9	16-Oct-2000	16-Oct-2006	(ggg)	N	
RP	Wilkins	975XLSEU	1	VUVU	9	16-Oct-2000	16-Oct-2006	(ggg)	N	
RP	Wilkins	975XLSEU	1 1/4	VUVD	9	27-Mar-2000	27-Mar-2006	(ggg)	N	
RP	Wilkins	975XLSEU	1 1/4	VUVU	9	27-Mar-2000	27-Mar-2006	(ggg)	N	
RP	Wilkins	975XLSEU	1 1/2	VUVD	9	27-Mar-2000	27-Mar-2006	(ggg)	N	
RP	Wilkins	975XLSEU	1 1/2	VUVU	9	27-Mar-2000	27-Mar-2006	(ggg)	N	
RP	Wilkins	975XLSEU	2	VUVD	9	27-Mar-2000	27-Mar-2006	(ggg)	N	
RP	Wilkins	975XLSEU	2	VUVU	9	27-Mar-2000	27-Mar-2006	(ggg)	N	
RP	Wilkins	975XLST	3/8	H	9	19-Nov-2002	19-Nov-2005	(ii)	N	
RP	Wilkins	975XLST	1/2	H	9	19-Nov-2002	19-Nov-2005	(ii)	N	
RP	Wilkins	975XLTCU	3/4	H	9	27-Jun-2006		(ggg)	N	
RP	Wilkins	975XLTCU	1	H	9	27-Jun-2006		(ggg)	N	
RP	Wilkins	975XLTCU	1 1/4	H	9	27-Jun-2006		(ggg)	N	
RP	Wilkins	975XLTCU	1 1/2	H	9	27-Jun-2006		(ggg)	N	
RP	Wilkins	975XLTCU	2	H	9	27-Jun-2006		(ggg)	N	
RP	Wilkins	975XLU	3/4	H	8	2-Sep-1993	2-Sep-2005	(ggg)	N	
RP	Wilkins	975XLU	1	H	8	2-Sep-1993	2-Sep-2005	(ggg)	N	
RP	Wilkins	975XLU	1 1/2	H	8	2-Sep-1993	2-Sep-2005	(ggg)	N	
RP	Wilkins	975XLU	2	H	8	2-Sep-1993	2-Sep-2005	(ggg)	N	
RP	Wilkins	975XLV	3/4	VUVD	9	7-Jan-2001	7-Jan-2004	(ii),ooo	N	
RP	Wilkins	975XLV	3/4	VUVU	9	7-Jan-2001	7-Jan-2004	(ii),ooo	N	
RP	Wilkins	975XLV	1	VUVD	9	7-Jan-2001	7-Jan-2004	(ii),ooo	N	
RP	Wilkins	975XLV	1	VUVU	9	7-Jan-2001	7-Jan-2004	(ii),ooo	N	
RPDA	Ames	5000	4	H	8	28-Dec-1989	28-Dec-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	N	Conbraco 4020402 3/4 (H)
RPDA	Ames	5000	6	H	8	28-Dec-1989	28-Dec-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	N	Conbraco 4020402 3/4 (H)
RPDA	Ames	5000	8	H	8	1-Jul-1989	1-Jul-2004	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	N	Conbraco 4020402 3/4 (H)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	γ_Spare Parts Onl	Bypass
RPDA	Ames	5000	10	H	8	19-Mar-1990	19-Mar-2005	(uu),ee,ff,gg,hh,ll,mm,oo,pp,tt,ccc,ddd,ffff,gggg	N	Conbraco 4020402 3/4 (H)
RPDA	Ames	5000CIV	2 1/2	H	8	7-Jul-2000	7-Jul-2006	(pp),hh,mm,uu	N	Watts 909QT 3/4 (H)
RPDA	Ames	5000CIV	3	H	8	7-Jul-2000	7-Jul-2006	(pp),hh,mm,uu,eee	N	Watts 909QT 3/4 (H)
RPDA	Ames	5000CIV	4	H	8	7-Jul-2000	7-Jul-2006	(pp),hh,mm,uu,eee	N	Watts 909QT 3/4 (H)
RPDA	Ames	5000CIV	6	H	8	7-Jul-2000	7-Jul-2006	(pp),hh,mm,uu,eee	N	Watts 909QT 3/4 (H)
RPDA	Ames	5000CIV	8	H	8	7-Jul-2000	7-Jul-2006	(pp),hh,mm,uu,eee	N	Watts 909QT 3/4 (H)
RPDA	Ames	5000CIV	10	H	8	7-Jul-2000	7-Jul-2006	(pp),hh,mm,uu,eee	N	Watts 909QT 3/4 (H)
RPDA	Ames	Colt 500-GV	2 1/2	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Ames	Colt 500-GV	3	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Ames	Colt 500-GV	4	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Ames	Colt 500-GV	6	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Ames	Maxim 500-GV	2 1/2	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Ames	Maxim 500-GV	3	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Ames	Maxim 500-GV	4	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Cla-Val	18-4	10	H	8	23-Aug-1990	23-Aug-2005	(hh),gg,qq,rr	Y	Cla-Val RP2 3/4 (H)
RPDA	Conbraco	40700C3	3	H	8	27-Jul-1993	27-Jul-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	40700E3	3	H	8	27-Jul-1993	27-Jul-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	4070AC3	4	H	8	27-Jul-1993	27-Jul-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	4070AE3	4	H	8	27-Jul-1993	27-Jul-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	4070CC3	6	H	8	20-Oct-1993	20-Oct-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	4070CE3	6	H	8	20-Oct-1993	20-Oct-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	4070EC3	8	H	8	24-May-1993	24-May-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	4070EE3	8	H	8	24-May-1993	24-May-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	4070GC3	10	H	8	13-Apr-1993	13-Apr-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Conbraco	4070GE3	10	H	8	13-Apr-1993	3-Apr-2005	(uu),cc,mm	N	Conbraco 4020402 3/4 (H)
RPDA	Febco	826YD	2 1/2	H	8	11-Nov-1988	11-Nov-2003	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 825Y 3/4 (H)
RPDA	Febco	826YD	3	H	8	11-Nov-1988	11-Nov-2003	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 825Y 3/4 (H)
RPDA	Febco	826YD	4	H	8	14-Oct-1988	14-Oct-2006	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 825Y 3/4 (H)
RPDA	Febco	826YD	6	H	8	1-Mar-1990	1-Mar-2005	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 825Y 3/4 (H)
RPDA	Febco	826YD	8	H	8	22-Jun-1990	22-Jun-2005	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 825Y 3/4 (H)
RPDA	Febco	826YD	10	H	8	22-Jun-1990	22-Jun-2005	(ff),mm,oo,pp,uu,zzz,ffff,gggg	N	Febco 825Y 3/4 (H)
RPDA	Neptune									
RPDA	Watts	009NRSRPDA	4	H	8	1-Feb-1995	1-Feb-2004	(oo),gg,ll,tt	Y	Watts 009M2QT 3/4 (H)
RPDA	Watts	009NRSRPDA	6	H	8	1-Feb-1995	1-Feb-2004	(oo),gg,ll,tt	Y	Watts 009M2QT 3/4 (H)
RPDA	Watts	009OSYRPDA	4	H	8	1-Feb-1995	1-Feb-2004	(pp),hh,mm,uu,zz	Y	Watts 009M2QT 3/4 (H)
RPDA	Watts	009OSYRPDA	6	H	8	1-Feb-1995	1-Feb-2004	(pp),hh,mm,uu,zz	Y	Watts 009M2QT 3/4 (H)
RPDA	Watts	909RPDA	2 1/2	H	8	16-Jun-1999	16-Jun-2005	(pp),hh,mm,uu,zz,ffff,gggg	N	Watts 909QT 3/4 (H)
RPDA	Watts	909RPDA	3	H	8	5-Oct-1988	5-Oct-2006	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 909QT 3/4 (H)
RPDA	Watts	909RPDA	4	H	8	9-Feb-1988	9-Feb-2006	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 909QT 3/4 (H)
RPDA	Watts	909RPDA	6	H	8	5-Oct-1988	5-Oct-2006	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 909QT 3/4 (H)
RPDA	Watts	909RPDA	8	H	8	14-Feb-1988	14-Feb-2006	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 909QT 3/4 (H)
RPDA	Watts	909RPDA	10	H	8	15-Feb-1988	15-Feb-2006	(pp),hh,mm,uu,zz,eee,ffff,gggg	N	Watts 909QT 3/4 (H)
RPDA	Watts	957RPDA-GV	2 1/2	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)

Type	Manufacturer	Model	Size	Orientation(s)	Manual	Approved	Renewal	Shutoffs	y_Spare Parts Onl	Bypass
RPDA	Watts	957RPDA-GV	3	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Watts	957RPDA-GV	4	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Watts	957RPDA-GV	6	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Watts	967RPDA-GV	2 1/2	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Watts	967RPDA-GV	3	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Watts	967RPDA-GV	4	H	9	20-Jun-2006		(zzz)	N	Watts 919QT 3/4" (H)
RPDA	Watts	990RPDA	4	H	8	1-Nov-1992	11-Nov-2004	(pp),hh,mm,uu,zz	Y	Watts 009QT 3/4 (H)
RPDA	Watts	990RPDA	8	H	8	13-Jan-1993	13-Jan-2005	(oo),gg,hh,ll,mm,pp,tt,uu	Y	Watts 009QT 3/4 (H)
RPDA	Watts	992RPDA	4	H	8	1-Nov-1992	11-Nov-2004	(oo)	Y	Watts 009QT 3/4 (H)
RPDA	Watts	992RPDA	10	H	8	13-Jan-1993	13-Jan-2005	(oo)	Y	Watts 009QT 3/4 (H)
RPDA	Wilkins	375ADA	4	H	9	2-Jun-2004		(qqq),ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4" (H)
RPDA	Wilkins	375ADA	6	H	9	25-Nov-2003		(qqq),ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	375ADA	8	H	9	15-Jun-2004		(qqq),ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4" (H)
RPDA	Wilkins	375DA	2 1/2	H	9	8-Oct-2002	8-Oct-2005	(hh),ff,mm,uu,zz	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	375DA	3	H	9	8-Oct-2002	8-Oct-2005	(hh),ff,mm,uu,zz	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	375DA	4	H	9	13-Dec-2000	13-Dec-2003	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	375DA	6	H	9	31-May-2001	31-May-2004	(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	375DA	8	H	9	15-Jun-2004		(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 975XLD 3/4" (H)
RPDA	Wilkins	375DA	10	H	9	22-Nov-2004		(hh),ff,mm,uu,zz,qqq,vvv,www,zzz,eeee	N	Wilkins 975XLD 3/4" (H)
RPDA	Wilkins	475DA	4	VUVD	9	20-Mar-2001	20-Mar-2004	(qqq),ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	475DA	6	VUVD	9	31-May-2001	31-May-2004	(qqq),ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	475DA	8	VUVD	9	11-Aug-2004		(qqq),ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	475DAV	4	VUVU	9	20-Mar-2001	20-Mar-2004	(qqq),mm,ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	475DAV	6	VUVU	9	20-Jul-2004		(qqq),mm,ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	475DAV	8	VUVU	9	24-Apr-2004		(qqq),mm,ttd,www,yyy,zzz,eeee	N	Wilkins 975XLD 3/4 (H)
RPDA	Wilkins	975DA	2 1/2	H	8	1-Feb-1994	1-Feb-2006	(hh),ff,uu,zz	N	Wilkins 975 3/4 (H)
RPDA	Wilkins	975DA	3	H	8	1-Feb-1994	1-Feb-2006	(hh),ff,uu,zz	N	Wilkins 975 3/4 (H)
RPDA	Wilkins	975DA	4	H	8	1-Nov-1993	1-Nov-2005	(hh),ff,uu,zz,qqq	N	Wilkins 975 3/4 (H)
RPDA	Wilkins	975DA	6	H	8	14-Mar-1994	14-Mar-2006	(hh),ff,uu,zz,qqq	N	Wilkins 975 3/4 (H)
RPDA	Wilkins	975DA	8	H	8	5-Dec-1996	5-Dec-2005	(hh),ff,uu,zz	N	Wilkins 975 3/4 (H)
RPDA	Wilkins	975DA	10	H	8	5-Dec-1996	5-Dec-2005	(hh),ff,uu,zz	N	Wilkins 975 3/4 (H)
SVB	Conbraco	SVB	1/4	H	9	30-Nov-2000	30-Nov-2003	(int)	N	
SVB	Conbraco	SVB	3/8	H	9	30-Nov-2000	30-Nov-2003	(int)	N	
SVB	Conbraco	SVB	1/2	H	9	30-Nov-2000	30-Nov-2003	(int)	N	
SVB	Watts	008PCQT	3/8	VUH	9	18-Nov-1998	18-Nov-2004	(vv),xx	N	
SVB	Watts	008PCQT	1/2	VUH	9	18-Nov-1998	18-Nov-2004	(vv),xx	N	
SVB	Watts	008PCQT	3/4	VUH	9	19-Jun-2000	19-Jun-2006	(vv),xx	N	
SVB	Watts	008PCQT	1	VUH	9	19-Jun-2000	19-Jun-2006	(vv),xx	N	







































Meters	Notes	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q		
(R)		
(S)		
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 3000SS prior to S/N 2EK0320	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 3000SS prior to S/N 2EK0320	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 3000SS prior to S/N 2EK0320	
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,N,O,P,Q		
(N), G, H, I J, K L, M, N, O, P, Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,N,O,P,Q		
(N), G, H, I J, K L, M, N, O, P, Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,N,O,P,Q		
(N), G, H, I J, K L, M, N, O, P, Q		
(K),A,B,C,D,E,F,G,H,I,J,L,M,N,O,P,Q		
(K),A,B,C,D,E,F,G,H,I,J,L,M,N,O,P,Q		
(K),A,B,C,D,E,F,G,H,I,J,L,M,N,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,N,O,P,Q		
(N), G, H, I J, K L, M, N, O, P, Q		

Meters	Notes	
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,N,O,P,Q		
(N), G, H, I, J, K, L, M, N, O, P, Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(M),F,G,H,I,J,K,L,N,O,P,Q		
(M),F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),E,F,G,H,I,J,K,L,N,O,P,Q		
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 4060003	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 4060003	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 4060A03	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q		
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 4060A03	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q		
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 4060C03	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q		
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	Formerly 4060C03	





Meters	Notes	
(N),A,B,C,D,E,F,G,H,I,J,K,L,M,O,P,Q	Formerly 709DDC	
(N),A,B,C,D,E,F,G,H,I,J,K,L,M,O,P,Q	Formerly 709DDC	
(H),A,B,C,D,E,F,G,I,J,K,L,M,N,O,P,Q		
(N),A,B,C,D,E,F,G,H,I,J,K,L,M,O,P,Q	Formerly 709DDC	
(H),A,B,C,D,E,F,G,I,J,K,L,M,N,O,P,Q		
(N),E,F,G,H,I,J,K,L,M,O,P,Q	Formerly 709DDC	
(H),A,B,C,D,E,F,G,I,J,K,L,M,N,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,N,O,P,Q		
(N), G, H, I J, K L, M, N, O, P, Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N), G, H, I J, K L, M, N, O, P, Q		
(N), G, H, I J, K L, M, N, O, P, Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N), G, H, I J, K L, M, N, O, P, Q		
(N), G, H, I J, K L, M, N, O, P, Q		
(N),G,H,I,J,K,L,M,O,P,Q		
(N),G,H,I,J,K,L,M,O,P,Q		













Meters	Notes	
	formerly 4020299T	
	formerly 40202A2S	
	formerly 4020399T	
	formerly 40203A2S	
	formerly 2020499T	
	formerly 40204A2S	
	formerly 40204A2U	
	formerly 40204A2Z	
	formerly 4020599T	
	formerly 40205A2S	
	formerly 40205A2U	
	formerly 40205A2Z	
	formerly 4020699T	
	formerly 40206A2U	
	formerly 40206A2Z	
	formerly 4020799T	
	formerly 40207A2U	
	formerly 40207A2Z	
	formerly 4020899T	
	formerly 40208A2U	
	formerly 40208A2Z	



























Meters	Notes	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q		
(H),C,D,E,F,G,I,J,K,L,M,N,O,P,Q		
(N),B,C,D,E,F,G,H,I,J,K,L,M,N,O,P,Q		
(N),B,C,D,E,F,G,H,I,J,K,L,M,N,O,P,Q		
(N),B,C,D,E,F,G,H,I,J,K,L,M,N,O,P,Q		
(N),B,C,D,E,F,G,H,I,J,K,L,M,N,O,P,Q		
(N),B,C,D,E,F,G,H,I,J,K,L,M,N,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		
(H),A,B,C,D,E,F,G,I,J,K,L,M,N,O,P,Q		
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070003	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070003	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070A03	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070A03	
(M),D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070C03	
(M),D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070CC3	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070E03	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070E03	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070G03	
(M),A,B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 4070G03	
(M),B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 826 Type YD	
(M),B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 826 Type YD	
(M),B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 826 Type YD	
(M),B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 826 Type YD	
(M),B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 826 Type YD	
(M),B,C,D,E,F,G,H,I,J,K,L,N,O,P,Q	formerly 826 Type YD	
	See Wilkins	
(H),D,E,F,G,I,J,K,L,M,N,O,P,Q		
(H),D,E,F,G,I,J,K,L,M,N,O,P,Q		
(H),D,E,F,G,I,J,K,L,M,N,O,P,Q		
(H),D,E,F,G,I,J,K,L,M,N,O,P,Q		
(H),C,D,E,F,G,H,I,J,K,L,M,O,P,Q		
(N),B,C,D,E,F,G,H,I,J,K,L,M,O,P,Q	formerly 909DDCM2	
(N),B,C,D,E,F,G,H,I,J,K,L,M,O,P,Q		
(N),B,C,D,E,F,G,H,I,J,K,L,M,O,P,Q	formerly 909DDC	
(N),B,C,D,E,F,G,H,I,J,K,L,M,O,P,Q		
(N),B,C,D,E,F,G,H,I,J,K,L,M,O,P,Q		
(N),H,I,J,K,L,M,N,O,P,Q		

